

# ISO 10516:2025-07 (E)

## Railway applications - Vehicle reference masses

---

<b>Contents</b>	<b>Page</b>
Foreword.....	iv
Introduction.....	v
<b>1 Scope</b> .....	<b>1</b>
<b>2 Normative references</b> .....	<b>1</b>
<b>3 Terms and definitions</b> .....	<b>1</b>
<b>4 Symbols</b> .....	<b>3</b>
<b>5 Calculation of vehicle reference masses</b> .....	<b>4</b>
5.1 General.....	4
5.2 Vehicle categories.....	5
5.3 Dead mass.....	5
5.4 Payload states.....	5
5.5 Reference masses.....	6
5.6 Special purpose mass definitions and payload states.....	7
<b>6 Consumables, staff and wear allowance</b> .....	<b>7</b>
<b>7 Standing area calculation</b> .....	<b>8</b>
<b>8 Payloads</b> .....	<b>8</b>
8.1 Passenger vehicles (M-I and M-II).....	8
8.2 Freight vehicles (M-III).....	9
<b>Annex A (normative) Payload parameters for mean population mass levels</b> .....	<b>10</b>
<b>Annex B (normative) Provisions on symbols and indices</b> .....	<b>12</b>
<b>Annex C (informative) Historically used abbreviated terms</b> .....	<b>13</b>
<b>Annex D (informative) Densities</b> .....	<b>14</b>
<b>Annex E (informative) Example for adapted standing area calculation parameters</b> .....	<b>15</b>
<b>Bibliography</b> .....	<b>16</b>