

# DIN ISO 20928:2019-06 (E)

## Tools for pressing - Spring plungers with helicoidal compression steel spring or gas spring (ISO 20928:2018)

---

<b>Contents</b>		<b>Page</b>
<b>National foreword</b> .....		<b>3</b>
<b>National Annex NA (informative)</b> .....		<b>4</b>
<b>Foreword</b> .....		<b>5</b>
<b>Introduction</b> .....		<b>6</b>
<b>1</b>	<b>Scope</b> .....	<b>7</b>
<b>2</b>	<b>Normative references</b> .....	<b>7</b>
<b>3</b>	<b>Terms and definitions</b> .....	<b>7</b>
<b>4</b>	<b>Basic principles</b> .....	<b>7</b>
<b>5</b>	<b>Calculation basics</b> .....	<b>7</b>
<b>6</b>	<b>Dimensions</b> .....	<b>7</b>
	6.1 Spring plunger with steel spring .....	<b>7</b>
	6.2 Spring plunger with gas spring .....	<b>8</b>
<b>7</b>	<b>Installation example</b> .....	<b>10</b>
<b>Bibliography</b> .....		<b>13</b>