

# DIN ISO 4126-10:2019-10 (E)

## Safety devices for protection against excessive pressure - Part 10: Sizing of safety valves for gas/liquid two-phase flow (ISO 4126 -10:2010)

---

<b>Contents</b>		<b>Page</b>
Foreword .....		5
Introduction .....		6
1	<b>Scope .....</b>	<b>7</b>
2	<b>Normative references .....</b>	<b>7</b>
3	<b>Terms and definitions .....</b>	<b>7</b>
4	<b>Symbols and abbreviated terms .....</b>	<b>13</b>
5	<b>Application range of the method .....</b>	<b>18</b>
5.1	<b>General .....</b>	<b>18</b>
5.2	<b>Limitations of the method for calculating the two-phase mass flux in safety valves .....</b>	<b>18</b>
5.3	<b>Limitations of the method for calculating the mass flow rate required to be discharged ...</b>	<b>19</b>
6	<b>Sizing steps .....</b>	<b>20</b>
6.1	<b>General outline of sizing steps .....</b>	<b>20</b>
6.2	<b>Step 1 -- Identification of the sizing case .....</b>	<b>21</b>
6.3	<b>Step 2 -- Flow regime at safety valve inlet .....</b>	<b>22</b>
6.4	<b>Step 3 -- Calculation of the flow rate required to be discharged .....</b>	<b>27</b>
6.5	<b>Step 4 -- Calculation of the dischargeable mass flux through a safety valve .....</b>	<b>34</b>
6.6	<b>Step 5 -- Proper operation of safety valves connected to inlet and outlet lines .....</b>	<b>40</b>
	<b>Annex A (informative) Identification of sizing scenarios .....</b>	<b>44</b>
	<b>Annex B (normative) Sizing of a safety valve .....</b>	<b>45</b>
	<b>Bibliography .....</b>	<b>50</b>