

# ISO 22241-3:2008-02 (E)

## Diesel engines - NOx reduction agent AUS 32 - Part 3: Handling, transportation and storage

---

<b>Contents</b>		<b>Page</b>
<b>Foreword</b> .....		<b>iv</b>
<b>1</b>	<b>Scope</b> .....	<b>1</b>
<b>2</b>	<b>Normative references</b> .....	<b>1</b>
<b>3</b>	<b>Terms and definitions</b> .....	<b>1</b>
<b>4</b>	<b>General requirements and recommendations</b> .....	<b>2</b>
4.1	Requirements for the use of materials compatible with AUS 32 .....	2
4.2	Physical conditions during transportation and storage .....	3
4.3	Cleanness of surfaces in contact with AUS 32 .....	4
4.4	Recommendation on further properties .....	4
<b>5</b>	<b>Quality assurance</b> .....	<b>4</b>
5.1	General .....	4
5.2	Sampling .....	5
5.3	Testing .....	5
5.4	Procedures for product release and handling of non-conforming product .....	5
5.5	Quality monitoring .....	6
<b>6</b>	<b>Procedures for handling of containers and equipment</b> .....	<b>7</b>
6.1	General .....	7
6.2	Single use non-bulk containers .....	7
6.3	Dedicated bulk operation .....	7
6.4	Non-dedicated bulk operation .....	8
<b>Bibliography</b> .....		<b>9</b>