

ISO 21218:2008-08 (E)

Intelligent transport systems - Communications access for land mobiles (CALM) - Medium service access points

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	Abbreviated terms	2
5	Requirements	4
5.1	Communication Module Adaptation	4
5.1.1	General	4
5.1.2	Communication Adaptation Layer	5
5.1.3	CI Management Adaptation Entity	5
5.2	Communication Interface	6
5.2.1	Classes	6
5.2.2	Access Classes	6
5.2.3	CI Identifier	7
5.2.4	Procedures	8
5.3	Virtual Communication Interface	15
5.3.1	Concept	15
5.3.2	VCI Identifier	16
5.3.3	Procedures	17
5.4	Communication SAP	18
5.4.1	LLC Types of Operation	18
5.4.2	Addressing	19
5.4.3	Service primitives (informative)	22
5.4.4	Priority	24
5.5	Management SAP	25
5.5.1	General	25
5.5.2	CIMAE-SETPARAM	25
5.5.3	CIMAE-GETPARAM	27
5.5.4	CIMAE-COMMAND	29
5.5.5	CIMAE-REQUEST	32
5.5.6	CIMAE-NOTIFY	35
5.5.7	MAC management frame	35
6	Conformance	36
7	Test methods	36
Annex A (normative) CI parameters		37
Annex B (normative) COMMANDs		54
Annex C (normative) REQUESTs		58
Annex D (normative) Error/return codes		61

Annex E (normative) ASN.1 definitions	62
Bibliography	72