ISO 13185-3:2018 (E)

Intelligent transport systems — Vehicle interface for provisioning and support of ITS Services — Part 3: Unified vehicle interface protocol (UVIP) server and client API specification

Contents

Foreword

Introduction

1 Scope

2 Normative references

3 Terms, definitions, symbols and abbreviated terms

4 Abbreviated terms

5 Conventions

6 UGP API concept

6.1 UGP client and server architecture
6.2 UGP communication flow
6.3 UGP interfaces and service primitives

7 UGP Java client API

7.1 UGP Java client API requests
7.1.1 Overview
7.1.2 authenticationReq
7.1.3 getSupportedDataReq
7.1.4 getValueReq
7.1.5 setValueReq
7.1.6 controlValueReq
7.1.7 getDtcInfoReq
7.1.8 clearDtcInfoReq
7.1.9 enablePassThruReq
7.1.10 listFileReq
7.1.11 manageFileUploadReq
7.1.12 manageFileDownloadReq
7.1.13 manageFileDeleteReq
7.1.14 resetReq
7.1.15 stopServiceReq
7.2 UGP Java Client API confirmations
7.2.1 Overview
7.2.2 authenticationConf
7.2.3 getSupportedDataConf
7.2.4 getValueConf
7.2.5 controlValueConf
7.2.6 getDtcInfoConf
7.2.7 listFileConf
7.2.8 manageFileConf
7.2.9 positiveConf
7.2.10 negativeConf

8 UGP Java server API

8.1 UGP Java server API indications
8.1.1 Overview
8.1.2 authenticationInd

8.1.3 getSupportedDataInd
8.1.4 getValueInd
8.1.5 setValueInd
8.1.6 controlValueInd
8.1.7 getDtcInfoInd
8.1.8 clearDtcInfoInd
8.1.9 enablePassThruInd
8.1.10 listFileInd
8.1.11 manageFileInd
8.1.12 resetInd
8.1.13 stopServiceInd
8.2 UGP Java server API responses
8.2.1 Overview
8.2.2 authenticationResp
8.2.3 getSupportedDataResp
8.2.4 getValueResp
8.2.5 controlValueResp
8.2.6 getDtcInfoResp
8.2.7 listFileResp
8.2.8 manageFileResp
8.2.9 positiveResp
8.2.10 negativeResp

Page count: 38