ISO 21806-2:2020 (E)

Road vehicles — Media Oriented Systems Transport (MOST) — Part 2: Application layer

Contents

Foreword

Introduction

1 Scope

2 Normative references

3 Terms and definitions

4 Symbols and abbreviated terms

4.1 Symbols
4.2 Abbreviated terms

5 Conventions

6 APP — Application

6.1 APP — Device model
6.2 APP — Node kinds
6.2.1 APP — MOST nodes
6.2.2 APP — Remote-controlled nodes
6.2.3 APP — Listen-only nodes
6.3 APP — Function block
6.3.1 APP — General
6.3.2 APP — FBlock library
6.3.3 APP — Controller and FBlock
6.4 APP — Functions
6.4.1 APP — Overview
6.4.2 APP — Methods
6.4.2.1 APP — Execution of methods
6.4.2.2 APP — Using methods with SenderHandle
6.4.2.3 APP — Using methods without SenderHandle
6.4.3 APP — Properties
6.4.3.1 APP — General
6.4.3.2 APP — Writing a property
6.4.3.3 APP — Reading a property
6.5 APP — Events and notification
6.5.1 APP — Events
6.5.2 APP — Notification
6.6 APP — Notification mechanisms
6.6.1 APP — General
6.6.2 APP — Notification function
6.6.3 APP — Implicit notification
6.6.4 APP — Automatic notification
6.6.5 APP — Errors in the context of the notification function
6.6.6 APP — No valid values or property failure
6.6.7 APP — Reactions on Configuration.Status events
6.7 APP — Requesting FBlock information
6.7.1 APP — Function FBlockIDs
6.7.2 APP — Function FktIDs
6.7.3 APP — Extended FBlock identification
6.8 APP — Registry management
6.8.1 APP — General

6.8.1.1 APP — Purpose
6.8.1.2 APP — Initialisation
6.8.1.2.1 APP — Configuration
6.8.1.2.2 APP — Initialisation of the central registry
6.8.1.2.3 APP — Initialisation on application level
6.8.1.3 APP — General operation — MOST network monitoring
6.8.2 APP — Central registry state
6.8.2.1 APP — Distribution of the central registry state
6.8.2.2 APP — Central registry state NotOK
6.8.2.3 APP — Central registry state OK
6.8.3 APP — NetworkMaster
6.8.3.1 APP — Overview
6.8.3.2 APP — Network change event
6.8.3.3 APP — Setting the central registry state
6.8.3.3.1 APP — Distributing the central registry state
6.8.3.3.2 APP — Setting the central registry state to OK
6.8.3.3.3 APP — Setting the central registry state to NotOK
6.8.3.4 APP — Central registry
6.8.3.4.1 APP — Overview
6.8.3.4.2 APP — Purpose
6.8.3.4.3 APP — Contents
6.8.3.4.4 APP — Responsibility
6.8.3.4.5 APP — Responding to requests for information from the central registry
6.8.3.5 APP — Specific behaviour after ev_Init_Ready
6.8.3.5.1 APP — Validity of logical node addresses
6.8.3.5.2 APP — Valid logical node address not available
6.8.3.5.3 APP — Valid logical node address available
6.8.3.6 APP — Scanning the MOST network
6.8.3.6.1 APP — FBlock scan
6.8.3.6.2 APP — Configuration request description
6.8.3.6.3 APP — NetworkMaster performs initial FBlock scan
6.8.3.6.4 APP — NetworkMaster performs rescan during central registry state OK
6.8.3.6.5 APP — Addressing
6.8.3.6.6 APP — Non-responding NetworkSlaves
6.8.3.6.7 APP — Duration of FBlock scanning
6.8.3.6.8 APP — Reporting the results of an FBlock scan
6.8.3.7 APP — Invalid announcements — Node address
6.8.3.8 APP — Invalid announcements — InstID
6.8.3.9 APP — Updates to the central registry
6.8.3.9.1 APP — Changes in central registry state OK
6.8.3.9.2 APP — Disappearing FBlocks in central registry state OK
6.8.3.9.2.1 APP — NetworkMaster reaction
6.8.3.9.2.2 APP — Own configuration invalid handling (optional)
6.8.3.9.3 Appearing FBlocks in central registry state OK
6.8.3.9.4 APP — FBlock scan without any change in central registry
6.8.3.9.5 APP — Non-responding nodes in central registry state OK
6.8.3.10 APP — Miscellaneous NetworkMaster requirements
6.8.3.10.1 APP — Network change event (NCE)
6.8.3.10.2 APP — Positioning of the FBlock NetworkMaster in the MOST network
6.8.4 APP — NetworkSlave
6.8.4.1 APP — General
6.8.4.2 APP — Decentral registry
6.8.4.2.1 APP — General
6.8.4.2.2 APP — Building a decentral registry
6.8.4.2.3 APP — Updating the decentral registry
6.8.4.2.4 APP — Deleting the decentral registry
6.8.4.3 APP — Specific behaviour after ev_Init_Ready
6.8.4.3.1 APP — Initialisation
6.8.4.3.2 APP — Valid logical node address not available
6.8.4.3.3 APP — Valid logical node address available
6.8.4.3.4 APP — Deriving the logical node address of the NetworkMaster
6.8.4.4 APP — Normal operation of the NetworkSlave
6.8.4.4.1 APP — Behaviour in central registry state OK
6.8.4.4.2 APP — Behaviour in central registry state NotOK

6.8.4.4.3 APP — Configuration requests and configuration changes
6.8.4.4.3.1 APP — General
6.8.4.4.3.2 APP — Responding to Configuration Requests by the NetworkMaster
6.8.4.4.3.3 APP — Reporting Configuration Changes to the NetworkMaster
6.8.4.4.4 APP — Unknown central registry state
6.8.4.4.5 APP — Determining the central registry state
6.8.4.4.6 APP — Reaction to Configuration.Status(OK) when in central registry state NotOK
6.8.4.4.7 APP — Reaction to Configuration.Status(OK) when in central registry state OK
6.8.4.4.8 APP — Reaction to Configuration.Status(NotOK) when in central registry state NotOK
6.8.4.4.9 APP — Reaction to Configuration.Status(NotOK) when in central registry state OK
6.8.4.4.10 APP — Reaction to Configuration.Status(NewExt)
6.8.4.4.11 APP — Reaction to Configuration.Status(Invalid)
6.8.4.4.12 APP — “Own configuration invalid” handling (optional)
6.9 APP — Network wake-up, startup, and shutdown
6.9.1 APP — General
6.9.2 APP — Network wake-up and startup
6.9.3 APP — Network shutdown
6.9.3.1 APP — General
6.9.3.2 APP — Error shutdown
6.9.3.3 APP — Emergency shutdown
6.9.3.4 APP — Normal shutdown
6.9.3.5 APP — Normal shutdown — Request stage
6.9.3.6 APP — Normal shutdown — Execution stage
6.9.4 APP — Device shutdown
6.9.4.1 APP — General
6.9.4.2 APP — Performing device shutdown
6.9.4.2.1 APP — Device shutdown stages
6.9.4.2.2 APP — Request stage (optional)
6.9.4.2.3 APP — Execution stage
6.9.4.3 APP — Exiting device shutdown
6.9.4.3.1 APP — General
6.9.4.3.2 APP — Exit due to PowerMaster
6.9.4.3.3 APP — Exit due to local condition
6.9.4.4 APP — Persistence of device shutdown
6.9.4.5 APP — Response when device shutdown is unsupported
6.10 APP — Connection management for streaming data
6.10.1 APP — Service for streaming data
6.10.1.1 APP — Streaming data
6.10.1.2 APP — Access to synchronous or isochronous data
6.10.1.3 APP — Differentiating synchronous data and isochronous data
6.10.1.4 APP — Synchronous data
6.10.1.5 APP — Isochronous data
6.10.2 APP — Source and sink information
6.10.2.1 APP — StreamDataInfo function
6.10.2.2 APP — Source functions
6.10.2.2.1 APP — SourceInfo function
6.10.2.2.2 APP — SourceName function
6.10.2.2.3 APP — SourceActivity function
6.10.2.3 APP — Sink functions
6.10.2.3.1 APP — SinkInfo function
6.10.2.3.2 APP — SinkName function
6.10.3 APP — Streaming connections
6.10.3.1 APP — Source functions
6.10.3.1.1 APP — Allocate function
6.10.3.1.2 APP — DeAllocate function
6.10.3.2 APP — Sink functions
6.10.3.2.1 APP — Connect function
6.10.3.2.2 APP — DisConnect function
6.10.3.2.3 APP — Mute function
6.10.3.3 APP — Connection manager
6.10.3.3.1 APP — General
6.10.3.3.2 APP — Deadlock prevention
6.10.3.4 APP — Establishing streaming connections
6.10.3.5 APP — Removing streaming connections

6.10.3.6 APP — Establishing DiscreteFrame isochronous streaming connections
6.10.3.7 APP — Removing DiscreteFrame isochronous streaming connections
6.10.3.8 APP — Monitoring streaming connections
6.10.3.9 APP — Handling of duplicate commands
6.10.3.9.1 APP — General
6.10.3.9.2 APP — Source behaviour
6.10.3.9.2.1 APP — Allocate
6.10.3.9.2.2 APP — DeAllocate
6.10.3.9.3 APP — Sink behaviour
6.10.3.9.3.1 APP — Connect
6.10.3.9.3.2 APP — DisConnect
6.10.4 APP — Compensating MOST network delay
6.11 APP — Diagnosis
6.11.1 APP — FBlock configuration status information
6.11.2 APP — Shutdown reason
6.11.3 APP — Shutdown reason analysis
6.11.4 APP — Ring break diagnosis
6.11.4.1 APP — Starting ring break diagnosis
6.11.4.2 APP — Ring break diagnosis result
6.11.5 APP — Network diagnosis
6.12 APP — Error handling
6.12.1 APP — General
6.12.2 APP — Handling overload in a message receiver
6.12.3 APP — Over-temperature management
6.12.3.1 APP — General over-temperature behaviour
6.12.3.2 APP — Mandatory over-temperature behaviour
6.12.3.3 APP — Optional over-temperature behaviour
6.12.3.3.1 APP — Common over-temperature behaviour
6.12.3.3.2 APP — Optional PowerMaster behaviour
6.12.3.3.3 APP — Optional PowerSlave behaviour
6.12.3.3.3.1 APP — Shutdown temperature level
6.12.3.3.3.2 APP — Restart temperature level
6.12.3.3.3.3 APP — Restart
6.13 APP — Timing definitions
6.13.1 APP — Definitions
6.13.1.1 APP — Exceptions to timing restrictions
6.13.1.2 APP — Timers
6.13.1.3 APP — Timing constraints
6.13.2 APP — NetworkMaster communication
6.13.2.1 APP — Overview
6.13.2.2 APP — Constraint tWaitBeforeScan
6.13.2.2.1 APP — Purpose
6.13.2.2.2 APP — Validity conditions
6.13.2.2.3 APP — Violation consequences
6.13.2.3 APP — Constraint tConfigurationAnnounce
6.13.2.3.1 APP — Purpose
6.13.2.3.2 APP — Validity conditions
6.13.2.3.3 APP — Violation consequences
6.13.2.4 APP — Timer tWaitForAnswer
6.13.2.4.1 APP — Purpose
6.13.2.4.2 APP — Start and Stop conditions
6.13.2.4.3 APP — Timer expiration
6.13.2.5 APP — Timer tDelayCfgRequest1
6.13.2.5.1 APP — Purpose
6.13.2.5.2 APP — Start and Stop conditions
6.13.2.5.3 APP — Timer expiration
6.13.2.6 APP — Timer tDelayCfgRequest2
6.13.2.6.1 APP — Purpose
6.13.2.6.2 APP — Start and Stop conditions
6.13.2.6.3 APP — Timer expiration
6.13.3 APP — PowerMaster communication
6.13.3.1 APP — Overview
6.13.3.2 APP — Timer tWaitSuspend
6.13.3.2.1 APP — Purpose

6.13.3.2.2 APP — Start and Stop conditions
6.13.3.2.3 APP — Timer expiration
6.13.3.3 APP — Timer tShutdownWait
6.13.3.3.1 Purpose
6.13.3.3.2 APP — Start and Stop conditions
6.13.3.3.3 APP — Timer expiration
6.13.3.4 APP — Timer tRetryShutdown
6.13.3.4.1 APP — Purpose
6.13.3.4.2 APP — Start and Stop conditions
6.13.3.4.3 APP — Timer expiration
6.13.3.5 APP — Timer tSlaveShutdown
6.13.3.5.1 APP — Purpose
6.13.3.5.2 APP — Start and Stop conditions
6.13.3.5.3 APP — Timer expiration

7 AL — Application layer

7.1 AL — Structure of MOST messages
7.2 AL — Addressing
7.2.1 AL — Overview
7.2.2 AL — 16-bit addressing
7.2.2.1 AL — Node position address
7.2.2.2 AL — Logical node address
7.2.2.3 AL — Dynamic logical node address
7.2.2.4 AL — Static logical node address
7.2.2.5 AL — Group address
7.2.2.6 AL — Blocking broadcast address
7.2.2.7 AL — Non-blocking broadcast address
7.2.2.8 AL — 16-bit address mapping
7.2.3 AL — 48-bit addressing (Ethernet MAC address)
7.3 AL — Function block identifier (FBlockID)
7.4 AL — Instance identifier (InstID)
7.4.1 AL — Distinction of FBlock instances
7.4.2 AL — Uniqueness of functional addresses
7.4.3 AL — Assigning InstID
7.4.4 AL — InstID of NetBlock FBlock
7.4.5 AL — InstID of NetworkMaster FBlock
7.4.6 AL — InstID of FBlock EnhancedTestability
7.4.7 AL — Wildcard values for InstID
7.5 AL — Function identifier (FktID)
7.6 AL — Operation type (OPType)
7.6.1 AL — Overview
7.6.2 AL — Set, Get and SetGet
7.6.3 AL — Increment and Decrement
7.6.4 AL — Status
7.6.5 AL — Start and StartAck
7.6.6 AL — StartResult and StartResultAck
7.6.7 AL — Result and ResultAck
7.6.8 AL — Processing and ProcessingAck
7.6.9 AL — Abort and AbortAck
7.6.10 AL — Error and ErrorAck
7.6.11 AL — Parameters
7.7 AL — Timing definitions
7.7.1 AL — Definitions
7.7.1.1 AL — Exceptions to timing restrictions
7.7.1.2 AL — Timers
7.7.1.3 AL — Timing constraints
7.7.2 AL — General communication
7.7.2.1 AL — Overview
7.7.2.2 AL — Constraint tProperty
7.7.2.2.1 AL — Purpose
7.7.2.2.2 AL — Validity conditions
7.7.2.2.3 AL — Violation consequences
7.7.2.3 Constraint tNotificationProperty
7.7.2.3.1 Purpose

7.7.2.3.2 AL — Validity conditions
7.7.2.3.3 AL — Violation consequences
7.7.2.4 AL — Timer tWaitForProperty
7.7.2.4.1 AL — Purpose
7.7.2.4.2 AL — Start and Stop conditions
7.7.2.4.3 AL — Timer expiration
7.7.2.5 AL — Timer tCM_DeadlockPrev
7.7.2.5.1 AL — Purpose
7.7.2.5.2 AL — Start and Stop conditions
7.7.2.5.3 AL — Timer expiration

8 PL — Presentation layer

8.1 PL — Data and basic data types
8.1.1 PL — General
8.1.2 PL — Boolean
8.1.3 PL — Enum
8.1.4 PL — Numeric data types
8.1.4.1 PL — FBlock library attributes for numeric data types
8.1.4.2 PL — Integer data types
8.1.4.2.1 PL — Attributes for integer data types
8.1.4.2.2 PL — Fixed-point representation of integers
8.1.4.2.3 PL — Bit-oriented representation of unsigned integers
8.1.4.2.4 PL — Unsigned Byte
8.1.4.2.5 PL — Signed Byte
8.1.4.2.6 PL — Unsigned Word
8.1.4.2.7 PL — Signed Word
8.1.4.2.8 PL — Unsigned Long
8.1.4.2.9 PL — Signed Long
8.1.4.2.10 PL — Unsigned Long Long
8.1.4.2.11 PL — Signed Long Long
8.1.4.3 PL — Floating-point data types
8.1.4.3.1 PL — Float
8.1.4.3.2 PL — Double
8.1.5 PL — Length-coded String
8.1.6 PL — Array Type
8.1.7 PL — Record Type
8.1.8 PL — Stream
8.1.8.1 PL — Attributes and values
8.1.8.2 PL — Stream parameter repetition
8.1.8.3 PL — Stream signals
8.1.8.4 PL — Stream cases
8.1.9 PL — BitField
8.1.10 PL — String
8.1.11 PL — Short Stream
8.1.12 PL — Classified Stream
8.2 PL — Function classes
8.2.1 PL — Purpose
8.2.2 PL — Properties with a single parameter
8.2.2.1 PL — Overview
8.2.2.2 PL — Function class Switch
8.2.2.3 PL — Function class Number
8.2.2.4 PL — Function class Text
8.2.2.5 PL — Function class Enumeration
8.2.2.6 PL — Function class Container
8.2.2.7 PL — Function class BoolField
8.2.2.8 PL — Function class BitSet
8.2.3 PL — Properties with multiple parameters
8.2.3.1 PL — Overview
8.2.3.2 PL — Function class DynamicArray
8.2.3.2.1 PL — General
8.2.3.2.2 PL — Editing in DynamicArrays
8.2.3.2.3 PL — Insertion of elements
8.2.3.2.4 PL — Deletion of elements
8.2.3.2.5 PL — Notification on DynamicArrays

8.2.3.3 PL — Function class LongArray
8.2.3.3.1 PL — General
8.2.3.3.2 PL — MotherArray
8.2.3.3.3 PL — ArrayWindow
8.2.3.3.4 PL — Inserting and deleting lines
8.2.3.3.5 PL — Positioning an ArrayWindow on a MotherArray
8.2.3.3.5.1 PL — MoveArrayWindow function
8.2.3.3.5.2 PL — Top and Bottom
8.2.3.3.5.3 PL — Up and Down
8.2.3.3.5.4 PL — Absolute
8.2.3.3.6 PL — Re-synchronization of ArrayWindows
8.2.3.4 PL — Function class Sequence Property
8.2.3.5 PL — Function class Collection
8.2.3.6 PL — Function class Record
8.2.3.7 PL — Function class Array
8.2.3.8 PL — Function class Map
8.2.3.8.1 PL — General
8.2.3.8.2 PL — Status transmission for function class Map
8.2.3.8.3 PL — Editing in function class Map: MapIns
8.2.3.8.4 PL — Editing in function class map: MapDel
8.2.4 PL — Function classes for methods
8.2.4.1 PL — Overview
8.2.4.2 PL — Function class Trigger Method
8.2.4.3 PL — Function class Sequence Method
9 Service interface definition to transport layer and network layer

Page count: 136