

# ISO 12156-1:2023-09 (E)

## Diesel fuel - Assessment of lubricity using the high-frequency reciprocating rig (HFRR) - Part 1: Test method

---

<b>Contents</b>		<b>Page</b>
Foreword.....		iv
Introduction.....		v
<b>1</b> Scope.....		<b>1</b>
<b>2</b> Normative references.....		<b>1</b>
<b>3</b> Terms and definitions.....		<b>1</b>
<b>4</b> Principle.....		<b>2</b>
<b>5</b> Reagents and materials.....		<b>2</b>
<b>6</b> Apparatus.....		<b>3</b>
<b>7</b> Sampling.....		<b>5</b>
<b>8</b> Preparation and calibration.....		<b>6</b>
8.1 Preparation of apparatus.....		6
8.1.1 Test plates and balls.....		6
8.1.2 Hardware.....		6
8.2 Calibration and correction.....		6
8.2.1 Temperature.....		6
8.2.2 Frequency.....		6
8.2.3 Stroke length.....		6
8.2.4 Test duration.....		6
8.2.5 Test rig performance.....		6
<b>9</b> Test procedure.....		<b>7</b>
<b>10</b> Measurement of wear scar.....		<b>8</b>
<b>11</b> Test results.....		<b>8</b>
<b>12</b> Precision.....		<b>8</b>
12.1 General.....		8
12.2 Repeatability, <i>r</i> .....		8
12.3 Reproducibility, <i>R</i> .....		9
<b>13</b> Test report.....		<b>9</b>
<b>Annex A (informative) Measurement of HFRR wear scars.....</b>		<b>10</b>
<b>Bibliography.....</b>		<b>13</b>