

# ISO 11157:2005-09 (E)

## Road vehicles - Brake lining assemblies - Inertia dynamometer test method

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms, definitions and symbols .....</b>	<b>1</b>
3.1	Terms and definitions .....	1
3.2	Symbols .....	2
<b>4</b>	<b>General .....</b>	<b>3</b>
<b>5</b>	<b>Test equipment .....</b>	<b>3</b>
<b>6</b>	<b>Test conditions .....</b>	<b>4</b>
<b>7</b>	<b>Test method .....</b>	<b>4</b>
7.1	General .....	4
7.2	Type-0 test (cold performance test) .....	4
7.3	Type-I test (fade test) .....	5
7.4	Type-II test (downhill behaviour test) .....	6
7.5	Type-III test (fade test) .....	7
<b>8</b>	<b>Assessment of test data and presentation of results .....</b>	<b>8</b>
8.1	Legal requirements and evaluation of test results .....	8
8.2	Type-0 test .....	8
8.3	Type-I, Type-II and Type-III test .....	9
8.4	Example of an assessment .....	9
<b>9</b>	<b>Inspection of brake linings or pads .....</b>	<b>10</b>
<b>Annex A (informative) Alternative equations for the calculation of the MFDD .....</b>		<b>16</b>
<b>Annex B (informative) Accuracy considerations .....</b>		<b>18</b>