

# DIN EN 1191:2013-04 (E)

## Windows and doors - Resistance to repeated opening and closing - Test method

---

<b>Contents</b>		<b>Page</b>
Foreword .....		4
Introduction .....		5
1 Scope .....		6
2 Normative references .....		6
3 Terms and definitions .....		7
4 Test equipment .....		9
4.1 Test rig .....		9
4.2 Operating equipment .....		9
4.3 Measuring equipment .....		9
4.4 Velocity measurement .....		10
5 Test requirements .....		10
5.1 General .....		10
5.2 Number of cycles .....		10
5.3 Reference velocity .....		10
5.4 Rest time .....		11
5.5 Operation of the fastening systems .....		11
6 Preparation for testing .....		12
7 Test procedure .....		12
7.1 Pre-test operation .....		12
7.2 Initial measurements .....		13
7.3 General cycle description .....		13
7.4 Measurements and maintenance .....		14
7.5 Stroke .....		15
7.6 Special cases .....		15
7.7 Final measurements .....		15
8 Test results .....		15
9 Test report .....		16
Annex A (normative) Test procedures for Tilt and Turn, Tilt-First, Turn-Only or Tilt-Only windows and door-height windows .....		17
A.1 Scope .....		17
A.2 General .....		17
A.3 Testing .....		17
Annex B (normative) Test procedures for Sliding, Lift and Slide or Lift and Slide and Tilt windows and door-height windows .....		23
B.1 Scope .....		23
B.2 Terms and definitions .....		23
B.3 General .....		24
B.4 Testing .....		24

<b>Annex C (normative) Test procedures for Tilt and Slide windows and door-height windows .....</b>	<b>28</b>
<b>C.1 Scope .....</b>	<b>28</b>
<b>C.2 Terms and definitions .....</b>	<b>28</b>
<b>C.3 General .....</b>	<b>29</b>
<b>C.4 Testing .....</b>	<b>29</b>
<b>Annex D (normative) Test procedures for Fold and Slide windows and door-height windows .....</b>	<b>34</b>
<b>D.1 Scope .....</b>	<b>34</b>
<b>D.2 General .....</b>	<b>34</b>
<b>D.3 Testing .....</b>	<b>34</b>
<b>Annex E (normative) Test procedures for horizontal or vertical pivot windows and door-height windows .....</b>	<b>37</b>
<b>E.1 Scope .....</b>	<b>37</b>
<b>E.2 Terms and definitions .....</b>	<b>37</b>
<b>E.3 General .....</b>	<b>38</b>
<b>E.4 Testing .....</b>	<b>38</b>
<b>Annex F (normative) Test procedures for Vertical Sliding windows .....</b>	<b>40</b>
<b>F.1 Scope .....</b>	<b>40</b>
<b>F.2 Terms and definitions .....</b>	<b>40</b>
<b>F.3 General .....</b>	<b>41</b>
<b>F.4 Testing .....</b>	<b>41</b>
<b>Annex G (normative) Test procedures for side-hung and top-hung windows, opening outwards (including reversible windows) .....</b>	<b>43</b>
<b>G.1 Scope .....</b>	<b>43</b>
<b>G.2 Terms and definitions .....</b>	<b>43</b>
<b>G.3 General .....</b>	<b>44</b>
<b>G.4 Testing .....</b>	<b>44</b>
<b>Annex H (normative) Test procedures for side-hung pedestrian doorsets excluding power operated doors .....</b>	<b>46</b>
<b>H.1 Scope .....</b>	<b>46</b>
<b>H.2 Terms and definitions .....</b>	<b>46</b>
<b>H.3 General .....</b>	<b>47</b>
<b>H.4 Testing .....</b>	<b>49</b>
<b>Annex I (normative) Test procedures for power-operated (automatic) side-hung single action pedestrian doorsets .....</b>	<b>52</b>
<b>I.1 Scope .....</b>	<b>52</b>
<b>I.2 Terms and definitions .....</b>	<b>52</b>
<b>I.3 General .....</b>	<b>52</b>
<b>I.4 Testing Test order .....</b>	<b>52</b>
<b>Bibliography .....</b>	<b>54</b>