

# DIN EN 1075:2015-03 (English)

## Timber structures - Test methods - Joints made with punched metal plate fasteners

---

<b>Contents</b>		<b>Page</b>
Foreword .....		4
<b>1</b>	<b>Scope .....</b>	<b>5</b>
<b>2</b>	<b>Normative references .....</b>	<b>5</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>5</b>
<b>4</b>	<b>Symbols and abbreviations .....</b>	<b>7</b>
<b>5</b>	<b>Materials .....</b>	<b>7</b>
<b>5.1</b>	<b>Timber .....</b>	<b>7</b>
<b>5.2</b>	<b>Fasteners .....</b>	<b>7</b>
<b>6</b>	<b>Test methods .....</b>	<b>8</b>
<b>6.1</b>	<b>General .....</b>	<b>8</b>
<b>6.2</b>	<b>Conditioning .....</b>	<b>8</b>
<b>6.3</b>	<b>Fabrication of test pieces .....</b>	<b>8</b>
<b>6.4</b>	<b>Preparation of test pieces .....</b>	<b>9</b>
<b>6.4.1</b>	<b>Anchorage capacity and load-slip characteristics of contact surface and timber: load parallel to grain .....</b>	<b>9</b>
<b>6.4.2</b>	<b>Anchorage capacity and load-slip characteristics of contact surface of fastener and timber: load not parallel to grain .....</b>	<b>10</b>
<b>6.4.3</b>	<b>Fastener tension capacity .....</b>	<b>11</b>
<b>6.4.4</b>	<b>Fastener compression capacity .....</b>	<b>12</b>
<b>6.4.5</b>	<b>Fastener shear capacity .....</b>	<b>13</b>
<b>6.5</b>	<b>Procedure .....</b>	<b>13</b>
<b>6.5.1</b>	<b>Estimation of maximum load .....</b>	<b>13</b>
<b>6.5.2</b>	<b>Loading procedure .....</b>	<b>13</b>
<b>6.5.3</b>	<b>Maximum load .....</b>	<b>14</b>
<b>6.6</b>	<b>Expression of results .....</b>	<b>15</b>
<b>6.6.1</b>	<b>Anchorage capacity .....</b>	<b>15</b>
<b>6.6.2</b>	<b>Fastener tension capacity .....</b>	<b>15</b>
<b>6.6.3</b>	<b>Fastener compression capacity .....</b>	<b>15</b>
<b>6.6.4</b>	<b>Fastener shear capacity .....</b>	<b>16</b>
<b>6.7</b>	<b>Determination of characteristic values .....</b>	<b>16</b>
<b>6.8</b>	<b>Test report .....</b>	<b>16</b>
<b>Annex A (normative)</b>	<b>Nail root test .....</b>	<b>17</b>
<b>A.1</b>	<b>Scope .....</b>	<b>17</b>
<b>A.2</b>	<b>Symbols .....</b>	<b>17</b>
<b>A.3</b>	<b>Test piece .....</b>	<b>17</b>
<b>A.4</b>	<b>Test method .....</b>	<b>17</b>
<b>A.5</b>	<b>Test results .....</b>	<b>17</b>
<b>Annex B (informative)</b>	<b>Derivation of rotational stiffness of the contact surface of the fastener and timber .....</b>	<b>19</b>
<b>B.1</b>	<b>General .....</b>	<b>19</b>
<b>B.2</b>	<b>Background to the calculations .....</b>	<b>19</b>
<b>B.3</b>	<b>Calculations .....</b>	<b>19</b>

<b>Annex C (informative) Examples of properly located transducers .....</b>	<b>21</b>
<b>Annex D (informative) Examples of loading arrangement .....</b>	<b>22</b>
<b>D.1 Fastener shear capacity .....</b>	<b>22</b>
<b>D.2 Fastener anchorage capacity: load not parallel to grain, (see 6.4.2) .....</b>	<b>24</b>
<b>Bibliography .....</b>	<b>25</b>