DIN EN 1026:2016-09 (E)

Windows and doors - Air permeability - Test method

Contents

Page

European foreword 3

1 Scope 5

2 Normative references 5

3 Terms and definitions 5

4 Principle of test 6

5 Test apparatus 6

6 Preparation of test specimen 7

7 Test procedure 7
7.1 Preliminaries 7
7.2 Air permeability of test chamber 7
7.2.1 General 7
7.2.2 Test chamber with known air permeability 7
7.2.3 Test chamber with unknown air permeability 7
7.3 Overall air permeability of test specimen and the test chamber - positive pressures 8
7.3.1 General 8
7.3.2 Measurement of air permeability for windows and external pedestrian doorsets 8
7.3.3 Measurement of air permeability for internal pedestrian doorsets 8
7.4 Overall air permeability of test specimen and the test chamber - negative pressures 8

8 Test result 8

9 Test report 9

Annex A (informative) Test pressure sequences 16

Bibliography 17