

DIN EN 1026:2016-09 (E)

Windows and doors - Air permeability - Test method

Contents		Page
European foreword		3
1	Scope	5
2	Normative references	5
3	Terms and definitions	5
4	Principle of test	6
5	Test apparatus	6
6	Preparation of test specimen	7
7	Test procedure	7
7.1	Preliminaries	7
7.2	Air permeability of test chamber	7
7.2.1	General	7
7.2.2	Test chamber with known air permeability	7
7.2.3	Test chamber with unknown air permeability	7
7.3	Overall air permeability of test specimen and the test chamber - positive pressures	8
7.3.1	General	8
7.3.2	Measurement of air permeability for windows and external pedestrian doorsets	8
7.3.3	Measurement of air permeability for internal pedestrian doorsets	8
7.4	Overall air permeability of test specimen and the test chamber - negative pressures	8
8	Test result	8
9	Test report	9
Annex A (informative) Test pressure sequences		16
Bibliography		17