

DIN EN 1026:2016-09 (E)

Windows and doors - Air permeability - Test method

Contents	Page
European foreword	3
1 Scope	5
2 Normative references	5
3 Terms and definitions	5
4 Principle of test	6
5 Test apparatus	6
6 Preparation of test specimen	7
7 Test procedure	7
7.1 Preliminaries	7
7.2 Air permeability of test chamber	7
7.2.1 General	7
7.2.2 Test chamber with known air permeability	7
7.2.3 Test chamber with unknown air permeability	7
7.3 Overall air permeability of test specimen and the test chamber - positive pressures	8
7.3.1 General	8
7.3.2 Measurement of air permeability for windows and external pedestrian doorsets	8
7.3.3 Measurement of air permeability for internal pedestrian doorsets	8
7.4 Overall air permeability of test specimen and the test chamber - negative pressures	8
8 Test result	8
9 Test report	9
Annex A (informative) Test pressure sequences	16
Bibliography	17