

ISO 13786:2017-06 (E)

Thermal performance of building components - Dynamic thermal characteristics - Calculation methods

| Contents | | Page |
|---|---|-------------|
| Foreword | | iv |
| Introduction | | v |
| 1 | Scope | 1 |
| 2 | Normative references | 1 |
| 3 | Terms and definitions | 1 |
| 3.1 | Definitions valid for any component | 2 |
| 3.2 | Definitions valid only for one dimensional heat flow | 3 |
| 3.3 | Other | 5 |
| 4 | Symbols and subscripts | 5 |
| 4.1 | Symbols | 5 |
| 4.2 | Subscripts | 6 |
| 4.3 | Specific symbols | 6 |
| 5 | Description of the method | 6 |
| 5.1 | Output | 6 |
| 5.2 | General description | 6 |
| 6 | Calculation of dynamic thermal properties | 6 |
| 6.1 | Output data | 6 |
| 6.2 | Calculation time intervals | 7 |
| 6.3 | Input data | 7 |
| 6.4 | Period of the thermal variations | 8 |
| 6.5 | Heat capacity | 8 |
| 7 | Heat transfer matrix of a multi-layer component | 8 |
| 7.1 | General | 8 |
| 7.2 | Procedure | 8 |
| 7.3 | Heat transfer matrix of a homogeneous layer | 9 |
| 7.4 | Heat transfer matrix of plane air cavities | 9 |
| 7.5 | Heat transfer matrix of a building component | 9 |
| 8 | Dynamic thermal characteristics | 10 |
| 8.1 | Characteristics for any component | 10 |
| 8.2 | Characteristics for components consisting of plane and homogeneous layers | 10 |
| 8.2.1 | Thermal admittances and periodic thermal conductances | 10 |
| 8.2.2 | Modified admittance for internal partitions | 10 |
| 8.2.3 | Areal heat capacities | 10 |
| 8.2.4 | Periodic thermal transmittance and decrement factor | 11 |
| 9 | Report | 11 |
| 9.1 | Calculation report | 11 |
| 9.2 | Summary of results | 12 |
| Annex A (normative) Input and method selection data sheet -- Template | | 13 |
| Annex B (informative) Input and method selection data sheet -- Default choices | | 15 |

| | |
|--|-----------|
| Annex C (normative)Simplifiedcalculationoftheheatcapacity | 17 |
| Bibliography | 19 |