ISO 13789:2017-06 (E)

Thermal performance of buildings - Transmission and ventilation heat transfer coefficients - Calculation method

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Terms and definitions 2

4 Symbols and subscripts 4
4.1 Symbols 4
4.2 Subscripts 4

5 Description of the method 5
5.1 Output 5
5.2 General description 5

6 Calculation of heat transfer coefficients 5
6.1 Output data 5
6.2 Calculation time intervals 7
6.3 Input data 7
6.4 Measurement of dimensions 8
6.5 Boundaries of conditioned space 8

7 Transmission heat transfer coefficient 10
7.1 Basic formula 10
7.2 Mean thermal transmittance of building fabric 10
7.3 Direct transmission between internal and external environments 11
7.4 Transmission heat transfer coefficient through the ground 12
7.5 Transmission heat transfer coefficient through unconditioned spaces 12
7.6 Heat transfer to adjacent buildings 13

8 Ventilation heat transfer coefficient 14

9 Additional conventions 14
9.1 General 14
9.2 Transmission heat transfer coefficient through the ground 14
9.3 Variable thermal transmittance 14
9.4 Air change rates of unconditioned spaces 14
9.5 Conventional values of surface heat transfer coefficient 15

10 Report 16

Annex A (normative) Input and method selection data sheet -- Template 17

Annex B (informative) Input and method selection data sheet -- Default choices 20

Annex C (normative) Temperature in an unconditioned space 23

Bibliography 24