

ISO 13789:2017-06 (E)

Thermal performance of buildings - Transmission and ventilation heat transfer coefficients - Calculation method

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions	2
4	Symbols and subscripts	4
4.1	Symbols	4
4.2	Subscripts	4
5	Description of the method	5
5.1	Output	5
5.2	General description	5
6	Calculation of heat transfer coefficients	5
6.1	Output data	5
6.2	Calculation time intervals	7
6.3	Input data	7
6.4	Measurement of dimensions	8
6.5	Boundaries of conditioned space	8
7	Transmission heat transfer coefficient	10
7.1	Basic formula	10
7.2	Mean thermal transmittance of building fabric	10
7.3	Direct transmission between internal and external environments	11
7.4	Transmission heat transfer coefficient through the ground	12
7.5	Transmission heat transfer coefficient through unconditioned spaces	12
7.6	Heat transfer to adjacent buildings	13
8	Ventilation heat transfer coefficient	14
9	Additional conventions	14
9.1	General	14
9.2	Transmission heat transfer coefficient through the ground	14
9.3	Variable thermal transmittance	14
9.4	Air change rates of unconditioned spaces	14
9.5	Conventional values of surface heat transfer coefficient	15
10	Report	16
Annex A (normative) Input and method selection data sheet -- Template		17
Annex B (informative) Input and method selection data sheet -- Default choices		20
Annex C (normative) Temperature in an unconditioned space		23
Bibliography		24