

### Contents

|         |  |
|---------|--|
|         | Foreword   |
|         | Introduction   |
| 1       | Scope  |
| 2       | Normative references   |
| 3       | Terms and definitions  |
| 4       | Symbols  |
| 5       | Materials  |
| 6       | Nominal loads  |
| 6.1     | Permanent loads  |
| 6.1.1   | General  |
| 6.1.2   | Equipment permanent loads                                    |
| 6.1.3   | Additional permanent loads                                   |
| 6.1.4   | Crash beam anchor guy pre-tension loads                      |
| 6.2     | Imposed loads (excluding rope loads)                         |
| 6.2.1   | General  |
| 6.2.2   | Floor and platform loads                                     |
| 6.2.3   | Bin material loads and chute material loads                  |
| 6.2.4   | Conveyance operating loads                                   |
| 6.2.5   | Headframe-mounted winder loads                               |
| 6.2.6   | Kibble loads   |
| 6.2.7   | Bank door operating loads                                    |
| 6.2.8   | Abnormal loads   |
| 6.2.9   | Earthquake loads   |
| 6.2.10  | Conveyance drop test loads                                   |
| 6.3     | Rope or conveyance installation loads                        |
| 6.3.1   | General  |
| 6.3.2   | Winding rope installation load                               |
| 6.3.3   | Winding rope doubling-down load                              |
| 6.3.4   | Tail rope installation or replacement load                   |
| 6.3.5   | Rope guide and rubbing rope installation or replacement load |
| 6.3.6   | Conveyance change over load                                  |
| 6.4     | Rope operating loads   |
| 6.4.1   | General  |
| 6.4.2   | Winding rope operating loads                                 |
| 6.4.3   | Stage rope operating loads                                   |
| 6.4.4   | Lateral rope operating loads on sheaves                      |
| 6.4.5   | Rope guide and rubbing rope operating loads                  |
| 6.5     | Emergency loads  |
| 6.5.1   | Emergency rope load  |
| 6.5.1.1 | Conveyances with fixed rope winders                          |
| 6.5.1.2 | Conveyances with friction winders                            |
| 6.5.1.3 | Stage emergency rope load                                    |
| 6.5.2   | Emergency dropback loads                                     |
| 6.5.3   | Crash beam and catch plate loads                             |
| 6.5.4   | Emergency arrestor anchor loads                              |
| 6.5.5   | Headframe-mounted winder emergency loads                     |
| 6.5.6   | Energy release loads following rope break                    |
| 6.5.7   | Dogging system loads   |

- 7**            **Design procedures**
  - 7.1**        **Design loads**
  - 7.2**        **Design standards**
  - 7.2.1**     **Design for emergency rope loads**
  - 7.3**        **Overall stability**
  - 7.4**        **Serviceability limit state**
    - 7.4.1**     **General**
    - 7.4.2**     **Deflection limits**
    - 7.4.3**     **Headframe-mounted winders**

**Annex A (informative) Load factors and load combinations**

- A.1**        **General**
- A.2**        **Operating conditions**
  - A.2.1**     **Partial load factors and load combination factors**
  - A.2.2**     **Load combinations**
- A.3**        **Emergency conditions**
  - A.3.1**     **Emergency load combinations with rope loads**
  - A.3.2**     **Emergency load combinations without rope loads**

**Page count: 14**