

ISO 21925-2:2021 (E)

Fire resistance tests — Fire dampers for air distribution systems — Part 2: Intumescent dampers

Contents

	Foreword
1	Scope
2	Normative references
3	Terms and definitions
4	Principles of the test
5	Apparatus
6	Test construction
6.1	General
6.1.1	Introduction
6.1.2	Side to be tested
6.1.3	Dampers installed in both walls and floors
6.1.4	Dampers installed within a structural opening
6.1.5	Dampers mounted onto face of wall or floor
6.1.6	Dampers remote from wall or floor
6.1.6.1	Within the furnace
6.1.6.2	Outside the furnace
6.1.7	Minimum separation between dampers
6.2	Size of specimen
6.3	Specimen installation
6.4	Supporting construction
6.4.1	Principles
6.4.2	Recommended supporting constructions
6.4.2.1	General
6.4.2.2	Non-standard supporting constructions
6.5	Conditioning
7	Determination of leakage of connecting duct and measuring station
8	Opening and closing cycles
9	Fire test
10	Classification and criteria
10.1	General
10.2	Number of tests required
11	Test report
12	Direct field of application of the test results
12.1	Size of fire damper
12.2	Fire dampers installed within structural openings
12.3	Fire dampers mounted onto the face of a wall
12.4	Fire dampers remote from a wall or floor
12.5	Separation between fire dampers and between fire dampers and construction elements
12.6	Supporting constructions
Annex A	(normative) Durability

- A.1 General
- A.2 Temperature and controlled humidity exposure
 - A.2.1 Temperature exposure to 70 °C
 - A.2.2 Controlled humidity exposure
 - A.2.3 Ambient temperature exposure
- A.3 Acceptance criteria after temperature and controlled humidity exposure

Annex B (informative) Test apparatus

Annex C (informative) Reaction to fire tests — Intumescent materials

- C.1 General
- C.2 Thermal activation temperature test
 - C.2.1 General
 - C.2.2 Apparatus
 - C.2.3 Test specimens
 - C.2.4 Test method
- C.3 Faulty set-off test
 - C.3.1 General
 - C.3.2 Apparatus
 - C.3.3 Test specimens
 - C.3.4 Test method
 - C.3.5 Performance
- C.4 Expansion pressure tests
 - C.4.1 General
 - C.4.2 Expansion pressure — Disc pressure test method
 - C.4.2.1 Apparatus
 - C.4.2.2 Test specimens
 - C.4.2.3 Test method
 - C.4.3 Expansion pressure — Pipe pressure test method
 - C.4.3.1 Apparatus
 - C.4.3.2 Test specimens
 - C.4.3.3 Test method
 - C.4.4 Expansion pressure - Die-set pressure method for covered, skinned or shaped specimens
 - C.4.5 Test report

Annex D (informative) The use and application of intumescent fire dampers in ducted air distribution systems

- D.1 General
- D.2 Properties
- D.3 Applications

Page count: 44