

DIN EN 17922:2024-08 (E)

Natural gas fuelling stations - LNG unloading stop system

Contents		Page
European foreword		3
Introduction		4
1	Scope	5
2	Normative references	5
3	Terms and definitions	5
4	Functional requirements	6
4.1	General requirement	6
4.2	Functional description of the unloading stop system	7
4.3	Alarms and actions for unloading stop system	8
4.3.1	Manual triggers for unloading stop	8
4.3.2	Automatic triggers for unloading stop	8
5	Design of the unloading stop system	10
5.1	General	10
5.2	Activation time	10
5.3	Air pressure alarm	10
6	Technical description of unloading stop system	10
6.1	Pneumatic system	10
6.1.1	General	10
6.1.2	Pressure rating	10
6.2	Pneumatic system connector	10
6.2.1	Technical drawing	10
6.2.2	Profile of the pneumatic connector	10
7	Operation of unloading stop system	11
7.1	Testing of the pneumatic link	11
7.2	Resume operation after ESD action	11
Bibliography		12