ISO 5124:2024-10 (E)

Loading and unloading of liquefied natural gas (LNG) tank wagons and containers

Contents

Page

Foreword iv

1 Scope 1

2 Normative references 1

3 Terms and definitions 1

4 Equipment design 3
4.1 LNG tank wagon 3
4.2 LNG tank container 3
4.3 Tanks for LNG tank wagons and tank containers 3
4.4 Loading or unloading bay configuration 6
4.5 Connection couplings 8
4.5.1 Type and size of connections 8
4.5.2 Quick connect disconnect coupler (QCDC) 8
4.5.3 Emergency release coupling (ERC) 8
4.6 LNG transfer hoses or arms 8
4.7 General process design requirements 9
4.7.1 General 9
4.7.2 Overfill detection and overpressurization 9
4.7.3 Loading and unloading process 10
4.7.4 Quantity and quality measurement 10
4.7.5 Sampling 11
4.7.6 Predicting LNG quality change due to ageing 11

5 Leak and fire management 11
5.1 Leak avoidance, detection and management 11
5.1.1 General 11
5.1.2 Avoidance 11
5.1.3 Gas detection 12
5.1.4 Management 12
5.2 Fire avoidance, detection and management strategies 13
5.2.1 Fire avoidance 13
5.2.2 Fire detection 13
5.2.3 Fire management 13

6 Layout considerations 13
6.1 Safety separation distances 13
6.2 Typical equipment layout 13
6.3 Buildings 13

7 Commissioning and start-up 14

8 Operations 15
8.1 Initial checks 15
8.2 Weighing before loading or unloading operation 15
8.3 Loading terminal 16

9 Stakeholder analysis 16

Bibliography 18