

# DIN EN 13015 :2008-12 (E)

Maintenance for lifts and escalators - Rules for maintenance instructions (includes Amendment A1:2008)

---

Contents	Page
<b>Foreword</b> .....	3
<b>0 Introduction</b> .....	3
<b>1 Scope</b> .....	3
<b>2 Normative references</b> .....	3
<b>3 Definitions</b> .....	4
<b>4 Elaboration of maintenance instructions</b> .....	5
<b>4.1 General</b> .....	5
<b>4.2 Elements to be taken into account for the maintenance instructions</b> .....	6
<b>4.3 Information to be included in the maintenance instructions</b> .....	6
<b>4.3.1 General</b> .....	6
<b>4.3.2 Information to the owner of the installation</b> .....	6
<b>4.3.3 Information for the maintenance organisation</b> .....	9
<b>5 Risk assessment</b> .....	10
<b>5.1 General</b> .....	10
<b>5.2 Information for the maintenance organisation</b> .....	11
<b>6 Information to the owner for lift rescue operations</b> .....	11
<b>7 Markings, signs, pictograms and written warnings</b> .....	12
<b>8 Format of the maintenance instruction handbook</b> .....	12
<b>Annex A (informative) Typical examples of checks to be taken into account in maintenance instructions</b> .....	13
<b>Annex B (informative) Examples of elements to be taken into account in risk assessment for maintenance operations</b> .....	17
<b>Annex ZA (informative) <span style="color: #0000ff;">[A]</span> Relationship between this European Standard and the Essential Requirements of EC Directive 98/37/EC <span style="color: #0000ff;">[A]</span></b> .....	19
<b>Annex ZB (informative) <span style="color: #0000ff;">[A]</span> Relationship between this European Standard and the Essential Requirements of EC Directive 2006/42/EC <span style="color: #0000ff;">[A]</span></b> .....	20
<b>Annex ZC (informative) <span style="color: #0000ff;">[A]</span> Relationship between this European Standard and the Essential Requirements of EC Directive 95/16/EC <span style="color: #0000ff;">[A]</span></b> .....	21