

# DIN EN 474-11:2010-05 (E)

## Earth-moving machinery - Safety - Part 11: Requirements for earth and landfill compactors (includes Amendment A1:2008)

---

<b>Contents</b>	<b>Page</b>
Foreword .....	3
Introduction .....	5
1 Scope .....	6
2 Normative references .....	6
3 Terms and definitions .....	6
4 List of additional significant hazards .....	7
5 Safety requirements and/or measures .....	7
5.1 General .....	7
5.2 Access .....	7
5.3 Operator's station .....	7
5.4 Fenders .....	8
5.5 Steering system .....	8
5.6 Braking system .....	8
5.7 Stability .....	8
5.8 Warning devices and safety signs .....	9
6 Information for use .....	9
Annex A (normative) List of additional significant hazards - Earth and landfill compactors .....	10
Annex B (informative) Illustrations .....	11
Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 98/37/EC .....	12
Annex ZB (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EC .....	13
Bibliography .....	14
Figures Figure B.1 -- Earth and landfill compactors with loading equipment .....	11
Figure B.2 -- Earth and landfill compactors with dozing equipment .....	11
Tables Table A.1 -- List of additional significant hazards .....	10