

# ISO 4254-8:2009-08 (E)

## Agricultural machinery - Safety - Part 8: Solid fertilizer distributors

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>2</b>
<b>4</b>	<b>Safety requirements and/or protective measures .....</b>	<b>2</b>
4.1	General .....	2
4.2	Stability when parked and for manual handling .....	2
4.3	Distributing components .....	3
4.4	Feeding components guarding .....	6
4.5	Loading .....	7
4.6	Checking of the hopper contents .....	9
4.7	Protection against ejection of fertilizer .....	9
4.8	Flow rate calibration system .....	9
4.9	Hitching and clearance zone .....	9
4.10	Noise .....	10
<b>5</b>	<b>Verification of the safety requirements and/or protective measures .....</b>	<b>11</b>
5.1	Stability when parked and for manual handling .....	11
5.2	Swivelling and movable components .....	11
<b>6</b>	<b>Information for use .....</b>	<b>11</b>
6.1	Operator's manual .....	11
6.2	Safety and instructional signs .....	12
<b>Annex A (informative) List of significant hazards .....</b>		<b>13</b>
<b>Annex B (informative) Stability of tractor solid fertilizer distributor combination .....</b>		<b>15</b>
<b>Bibliography .....</b>		<b>16</b>