

# DIN EN ISO 14314:2010-01 (E)

## Reciprocal internal combustion engines - Recoil starting equipment - General safety requirements (ISO 14314:2004)

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
Introduction .....		4
<b>1</b>	<b>Scope .....</b>	<b>5</b>
<b>2</b>	<b>Normative references .....</b>	<b>5</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>5</b>
<b>4</b>	<b>List of significant hazards .....</b>	<b>6</b>
<b>5</b>	<b>Safety requirements and/or protective measures .....</b>	<b>6</b>
5.1	General .....	6
5.2	Hazards .....	7
5.2.1	Crushing hazard .....	7
5.2.2	Cutting/severing hazard .....	7
5.2.3	Drawing-in or trapping hazard .....	7
5.2.4	Unhealthy posture or excessive effort .....	7
5.2.5	Ejected object .....	7
5.2.6	Slip/trip and fall of the operator .....	8
<b>6</b>	<b>Verification of safety requirements and/or protective measures .....</b>	<b>8</b>
<b>7</b>	<b>Information for use .....</b>	<b>8</b>
7.1	General .....	8
7.2	Technical data .....	8
7.3	Marking .....	8
<b>Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 98/37/EC .....</b>		<b>10</b>
<b>Annex ZB (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EC .....</b>		<b>11</b>