

# DIN EN ISO 4254-5:2011-05 (E)

Agricultural machinery - Safety - Part 5: Power-driven soil-working machines (ISO 4254-5:2008) (includes Corrigendum AC:2011)

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
Introduction .....		4
<b>1</b>	<b>Scope .....</b>	<b>5</b>
<b>2</b>	<b>Normative references .....</b>	<b>5</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>6</b>
<b>4</b>	<b>Safety requirements and/or measures .....</b>	<b>6</b>
<b>4.1</b>	<b>General .....</b>	<b>6</b>
<b>4.2</b>	<b>Noise reduction at the design stage .....</b>	<b>6</b>
<b>4.3</b>	<b>Protection against inadvertent contact with power-driven tools .....</b>	<b>6</b>
<b>4.4</b>	<b>Adjustment of working depth .....</b>	<b>11</b>
<b>5</b>	<b>Verification of safety requirements or protective measures .....</b>	<b>13</b>
<b>6</b>	<b>Information for use .....</b>	<b>13</b>
<b>6.1</b>	<b>Operator's manual .....</b>	<b>13</b>
<b>6.2</b>	<b>Safety and instructional signs .....</b>	<b>13</b>
	<b>Annex A (informative) List of significant hazards .....</b>	<b>14</b>
	<b>Annex B (informative) Examples of power-driven soil working machines .....</b>	<b>18</b>
	<b>Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EC .....</b>	<b>19</b>