

# ISO 11525-1:2012-07 (E)

## Rough-terrain trucks - User requirements - Part 1: General requirements

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>General safety requirements .....</b>	<b>2</b>
4.1	Principles .....	2
4.2	Operator's manual(s) .....	3
4.3	Modifications or alterations .....	3
4.4	Manufacturer's bulletins .....	3
4.5	Operator qualifications .....	3
4.6	Operator's responsibility for training .....	3
4.7	Operator training .....	3
4.8	Inspection and maintenance .....	6
4.9	Hazardous environments .....	8
<b>5</b>	<b>Operating safety rules and precautions .....</b>	<b>8</b>
5.1	Operator's responsibility for safety .....	8
5.2	Visual inspection and functional tests .....	9
5.3	General operating instructions .....	9
5.4	Travelling .....	11
5.5	Picking and placing loads .....	12
5.6	Using attachments .....	12
Bibliography .....		14