

# ISO 9927-1:2013-06 (E)

## Cranes - Inspections - Part 1: General

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>General .....</b>	<b>2</b>
<b>4.1</b>	<b>General .....</b>	<b>2</b>
<b>4.2</b>	<b>Instructions .....</b>	<b>2</b>
<b>5</b>	<b>Inspections .....</b>	<b>2</b>
<b>5.1</b>	<b>General .....</b>	<b>2</b>
<b>5.2</b>	<b>Daily inspection .....</b>	<b>3</b>
<b>5.3</b>	<b>Frequent inspection .....</b>	<b>3</b>
<b>5.4</b>	<b>Periodic inspection .....</b>	<b>3</b>
<b>5.5</b>	<b>Exceptional inspection .....</b>	<b>4</b>
<b>5.6</b>	<b>Major inspection .....</b>	<b>4</b>
<b>5.7</b>	<b>Enhanced periodic inspection .....</b>	<b>5</b>
<b>6</b>	<b>Methods of inspection .....</b>	<b>6</b>
<b>6.1</b>	<b>Visual examination .....</b>	<b>6</b>
<b>6.2</b>	<b>Non-destructive test .....</b>	<b>6</b>
<b>6.3</b>	<b>Functional test .....</b>	<b>6</b>
<b>6.4</b>	<b>No-load test .....</b>	<b>6</b>
<b>6.5</b>	<b>Load test .....</b>	<b>7</b>
<b>6.6</b>	<b>Static, dynamic and stability tests .....</b>	<b>7</b>
<b>7</b>	<b>Inspection personnel .....</b>	<b>7</b>
<b>8</b>	<b>Precautions for inspection .....</b>	<b>7</b>
<b>9</b>	<b>Repairs .....</b>	<b>7</b>
<b>10</b>	<b>Records .....</b>	<b>7</b>
<b>10.1</b>	<b>General .....</b>	<b>7</b>
<b>10.2</b>	<b>Logbook .....</b>	<b>7</b>
<b>10.3</b>	<b>Inspection records .....</b>	<b>8</b>
<b>11</b>	<b>Change of rated capacity .....</b>	<b>8</b>
<b>12</b>	<b>Limiting and indicating devices .....</b>	<b>8</b>
<b>Annex A (informative) Checklist to determine suitability of user organization instructions .....</b>		<b>9</b>
<b>Annex B (informative) Inspection flowcharts .....</b>		<b>12</b>
<b>Annex C (informative) Inspection precautions .....</b>		<b>16</b>
<b>Annex D (normative) Competent persons for the type of inspection .....</b>		<b>17</b>