

ISO 12140:2013-07 (E)

Agricultural machinery - Agricultural trailers and trailed equipment - Drawbar jacks

| Contents | | Page |
|--------------------|--|-------------|
| Foreword | | iv |
| 1 | Scope | 1 |
| 2 | Normative references | 1 |
| 3 | Terms and definitions | 1 |
| 4 | Requirements | 4 |
| 4.1 | Crank effort | 4 |
| 4.2 | Overtravel | 4 |
| 4.3 | Ground pressure | 4 |
| 4.4 | Corrosion protection | 4 |
| 4.5 | Service life | 4 |
| 4.6 | Rated static compressive load capacity | 4 |
| 4.7 | Rated dynamic compressive load capacity | 4 |
| 4.8 | Rated static tensile load capacity | 4 |
| 4.9 | Rated dynamic tensile load capacity | 5 |
| 4.10 | Rated static side load capacity | 5 |
| 4.11 | Rated static side torque class | 5 |
| 4.12 | Crank assembly | 5 |
| 4.13 | Prevention of ground contact when not in use | 5 |
| 4.14 | Security in operating position | 6 |
| 4.15 | Hydraulic components and fittings | 6 |
| 4.16 | Application performance | 6 |
| 5 | Marking | 7 |
| 6 | Acceptance tests -- Installation and procedures | 8 |
| 6.1 | General procedures and installation of jack | 8 |
| 6.2 | Jack stand system design verification tests | 8 |
| 6.3 | Jack stand system application tests | 9 |
| 7 | Information for use | 10 |
| Bibliography | | 11 |