

DIN EN 13001-2:2014-12 (E)

Crane safety - General design - Part 2: Load actions

Contents		Page
Foreword		3
Introduction		4
1	Scope	5
2	Normative references	5
3	Terms, definitions, symbols and abbreviations	5
3.1	Terms and definitions	5
3.2	Symbols and abbreviations	6
4	Safety requirements and/or measures	10
4.1	General	10
4.2	Loads	10
4.2.1	General	10
4.2.2	Regular loads	11
4.2.3	Occasional loads	18
4.2.4	Exceptional loads	25
4.3	Load combinations	33
4.3.1	General	33
4.3.2	High risk situations	34
4.3.3	Favourable and unfavourable masses	34
4.3.4	Partial safety factors for the mass of the crane	35
4.3.5	Partial safety factors to be applied to loads determined by displacements	36
4.3.6	Load combinations for the proof of competence	37
4.3.7	The proof of crane stability	40
Annex A (informative)	Aerodynamic coefficients	42
A.1	General	42
A.2	Individual members	45
A.3	Plane and spatial lattice structure members	51
A.4	Structural members in multiple arrangement	53
Annex B (informative)	Illustration of the types of hoist drives	55
Annex C (informative)	Calculation of load factor for indirect lifting force limiter	58
Annex D (informative)	Guidance on selection of the risk coefficient	60
Annex E (informative)	Selection of a suitable set of crane standards for a given application	62
Annex ZA (informative)	Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EC	63
Bibliography		64