

ISO 9928-1:2015-06 (E)

Cranes - Crane operating manual - Part 1: General

| Contents | | Page |
|-----------------|----------------------------------------------|-------------|
| Foreword | | iv |
| 1 | Scope | 1 |
| 2 | Normative references | 1 |
| 3 | Terms and definitions | 1 |
| 4 | Presentation of the manual | 1 |
| 4.1 | General | 1 |
| 4.2 | Preliminary information | 2 |
| 4.3 | Number of books | 2 |
| 5 | of the operating manual | 2 |
| 5.1 | Technical data | 2 |
| 5.2 | Special safety advice | 2 |
| 5.2.1 | Crane | 2 |
| 5.2.2 | Operating area | 3 |
| 5.2.3 | Setting up of the crane | 3 |
| 5.2.4 | Securing of the crane | 3 |
| 5.2.5 | Working clothes and personal equipment | 3 |
| 5.3 | Operator's aids and controls | 3 |
| 5.4 | Operator's instructions | 3 |
| 5.5 | Load diagrams and load tables | 3 |
| 5.6 | Safety devices | 3 |
| 5.7 | Environmental conditions | 3 |