

ISO/TS 6336-20:2017-11 (E)

Calculation of load capacity of spur and helical gears - Part 20: Calculation of scuffing load capacity (also applicable to bevel and hypoid gears) - Flash temperature method

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions, symbols and units	1
3.1	Terms and definitions	1
3.2	Symbols and units	1
4	Scuffing and wear	5
4.1	Occurrence of scuffing and wear	5
4.2	Transition diagram	6
4.3	Friction at incipient scuffing	7
5	Basic formulae	7
5.1	Contact temperature	7
5.2	Flash temperature formula	9
5.3	Transverse unit load	10
5.4	Distribution of overall bulk temperatures	11
5.5	Rough approximation of a bulk temperature	12
6	Coefficient of friction	12
6.1	General	12
6.2	Mean coefficient of friction, method A	13
6.3	Mean coefficient of friction, method B	13
6.4	Mean coefficient of friction, method C	13
7	Parameter on the line of action	14
8	Approach factor	16
9	Load sharing factor, X	17
9.1	General	17
9.2	Spur gears with unmodified profiles	17
9.3	Spur gears with profile modification	18
9.4	Buttressing factor, X_{but},	20
9.5	Helical gears with 0,8 and unmodified profiles	21
9.6	Helical gears with 0,8 and profile modification	21
9.7	Helical gears with 1,2 and unmodified profiles	22
9.8	Helical gears with 1,2 and profile modification	22
9.9	Helical gears with $0,8 < < 1,2$	24
9.10	Narrow bevel gears	24
9.11	Wide bevel gears	24
10	Scuffing temperature and safety	26
10.1	Scuffing temperature	26

10.2	Structural factor	26
10.3	Contact exposure time	27
10.4	Scuffing temperature in gear tests	28
10.5	Safety range	28
Annex A (informative) Flash temperature formula presentation		30
Annex B (informative) Optimal profile modification		37
Bibliography		39