

# ISO 19014-3:2018 (E)

## Earth-moving machinery — Functional safety — Part 3: Environmental performance and test requirements of electronic and electrical components used in safety-related parts of the control system

---

### Contents

	Foreword
	Introduction
1	Scope
2	Normative references
3	Terms and definitions
4	Functional status classifications
4.1	Class A
4.2	Class B
4.3	Class C
4.4	Class D
5	Tests and requirements
5.1	General
5.2	Dust
5.2.1	Purpose
5.2.2	Test method
5.3	Chemical resistance
5.3.1	Purpose
5.3.2	Test method
5.4	Salt spray
5.4.1	Purpose
5.4.2	Test method
5.5	Pressure wash
5.5.1	Purpose
5.5.2	Test method
5.6	Random vibration
5.6.1	Purpose
5.6.2	Test method
5.7	Operating shock
5.7.1	Purpose
5.7.2	Test method
5.8	Temperature cycles
5.8.1	Purpose
5.8.2	Test method
5.9	Thermal shock
5.9.1	Purpose
5.9.2	Test method
5.10	Humidity cycles
5.10.1	Purpose
5.10.2	Test method
5.11	Overvoltage condition
5.11.1	Purpose
5.11.2	Test method
5.12	Undervoltage condition (reset behaviour at voltage drop)
5.12.1	Purpose
5.12.2	Test method
5.13	Electromagnetic compatibility

- 5.13.1 Purpose
- 5.13.2 Test method
- 5.14 Reverse polarity
- 5.14.1 Purpose
- 5.14.2 Test method

**Annex A (informative) Test checklist**

**Page count: 11**