

ISO 6750-1:2019-10 (E)

Earth-moving machinery - Operator's manual - Part 1: Contents and format

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	General information for operator's manuals	4
4.1	General information	4
4.2	Machine configurations	4
4.3	Attachments, tools, additional equipment	5
4.4	Units of measurement	5
4.5	Original language and translations	5
4.6	Graphical symbols	5
4.7	Meaning of audible and visual signals on the machine	5
4.8	Basic information	5
5	Content of operator's manuals	5
5.1	General	5
5.2	Identification of the operator's manual	5
5.3	Table of contents	6
5.4	Identification of the machine	6
5.5	Introduction	7
5.6	Safety information	8
5.6.1	Residual risks	8
5.6.2	Safety alert symbol	8
5.6.3	Signal words	8
5.6.4	Safety messages	8
5.6.5	Machine safety labels	9
5.7	Operation	11
5.7.1	General	11
5.7.2	Controls and displays	11
5.7.3	Operating instructions	11
5.8	Troubleshooting	11
5.9	Maintenance and adjustments	12
5.9.1	General	12
5.9.2	Precautions prior to maintenance	12
5.9.3	Maintenance instructions for the operator	12
5.10	Spare parts list	13
5.11	Preservation and storage	13
5.11.1	General	13
5.11.2	Prior to long-term storage	13
5.11.3	After long-term storage	13
5.12	End of service life information	13
5.13	Specifications -- Machine technical data	14
Annex A (normative)	Basic information for inclusion in operator's manual	15
Annex B (informative)	Presentation and format of the operator's manual -- Recommendations	18
Annex C (informative)	Electronic media	21
Bibliography		23