

ISO 11525-2:2020-01 (E)

Rough-terrain trucks - Safe use requirements - Part 2: Slewing variable-reach trucks

Contents	Page
Foreword	iv
Introduction	v
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 General requirements	2
4.1 Principles.....	2
4.2 Operator's manual(s).....	2
4.3 Modifications or alterations.....	2
4.4 Manufacturer's bulletins.....	3
4.5 Operator qualifications and training.....	3
4.6 Inspection and maintenance.....	3
4.6.1 General.....	3
4.6.2 Preparation for inspection or repair.....	3
4.6.3 Performance checks.....	4
4.6.4 Inspection and maintenance precautions.....	5
4.6.5 Inspection and maintenance requirements.....	5
4.7 Hazardous environments.....	6
4.8 Refuelling.....	6
5 Operating safety rules and precautions	6
5.1 Operator's responsibility for safety.....	6
5.2 Visual inspection and functional tests.....	7
5.3 General operating instructions.....	8
5.4 Travelling.....	9
5.5 Picking and placing loads.....	10
5.6 Using attachments.....	11
Bibliography	13