

ISO 11525-1:2020-01 (E)

Rough-terrain trucks - Safe use requirements - Part 1: Variable-reach trucks

Contents		Page
Foreword		iv
1 Scope		1
2 Normative references		1
3 Terms and definitions		1
4 General requirements		2
4.1 Principles.....		2
4.2 Operator's manual(s).....		3
4.3 Modifications or alterations.....		3
4.4 Manufacturer's bulletins.....		3
4.5 Operator qualifications and training.....		4
4.6 Inspection and maintenance.....		4
4.6.1 General.....		4
4.6.2 Preparation for inspection or repair.....		4
4.6.3 Performance checks.....		4
4.6.4 Inspection and maintenance precautions.....		5
4.6.5 Inspection and maintenance requirements.....		6
4.7 Hazardous environments.....		6
4.8 Refuelling.....		7
5 Operating safety rules and precautions		7
5.1 Operator's responsibility for safety.....		7
5.2 Visual inspection and functional tests.....		7
5.3 General operating instructions.....		8
5.4 Travelling.....		10
5.5 Picking and placing loads.....		11
5.6 Using attachments.....		12
Bibliography		13