

# ISO 4254-6:2020-04 (E)

## Agricultural machinery - Safety - Part 6: Sprayers and liquid fertilizer distributors

<b>Contents</b>	<b>Page</b>
<b>Foreword</b> .....	<b>iv</b>
<b>Introduction</b> .....	<b>v</b>
<b>1 Scope</b> .....	<b>1</b>
<b>2 Normative references</b> .....	<b>1</b>
<b>3 Terms and definitions</b> .....	<b>1</b>
<b>4 Safety requirements and/or protective measures</b> .....	<b>2</b>
4.1 General .....	2
4.2 Stability of machines fitted with rollers for manual handling when dismantled .....	2
4.3 Spray boom folding .....	2
4.4 Adjustment of spray boom height .....	2
4.4.1 Manual height adjustment .....	2
4.4.2 Powered height adjustment .....	3
4.5 Spray tank .....	3
4.5.1 Prevention of whole-body access to the tank .....	3
4.5.2 Limitation of contact with chemicals .....	3
4.5.3 Prevention of spillage and overflow .....	4
4.5.4 Protection from contact with spray mixture when draining .....	4
4.6 Pressure indicator (manometer) .....	5
4.7 Protection against overpressure .....	5
4.8 Fan for air-assistance .....	5
4.9 Spray liquid carrying hoses .....	6
4.10 Spraying stop control .....	6
4.11 Clean water tank .....	6
4.12 Storage of personal protective equipment .....	6
4.13 Hitching and clearance zone .....	6
4.14 Servicing and maintenance .....	7
4.15 Noise reduction at the design stage .....	7
<b>5 Verification of the safety requirements and/or protective measures</b> .....	<b>7</b>
<b>6 Information for use</b> .....	<b>9</b>
6.1 Operator's manual .....	9
6.2 Marking .....	10
6.2.1 General .....	10
6.2.2 Sprayers .....	10
6.2.3 Product pump .....	10
<b>Annex A (informative) List of significant hazards</b> .....	<b>12</b>
<b>Bibliography</b> .....	<b>19</b>