

# ISO 10968:2020-05 (E)

## Earth-moving machinery - Operator's controls

---

| <b>Contents</b>  | <b>Page</b> |
|--|-------------|
| <b>Foreword</b> .....  | <b>iv</b>   |
| <b>Introduction</b> .....  | <b>v</b>    |
| <b>1 Scope</b> .....   | <b>1</b>    |
| <b>2 Normative references</b> .....                                    | <b>1</b>    |
| <b>3 Terms and definitions</b> .....                                   | <b>1</b>    |
| <b>4 Requirements for controls</b> .....                               | <b>4</b>    |
| 4.1 General.....   | 4           |
| 4.2 Control locations.....   | 4           |
| 4.3 Distance between controls.....                                     | 4           |
| 4.4 Measures against movement or damage by external forces.....        | 5           |
| 4.5 Pedals.....  | 6           |
| <b>5 Movement of controls</b> .....                                    | <b>6</b>    |
| 5.1 General.....   | 6           |
| 5.2 Multifunction controls.....  | 6           |
| 5.2.1 General.....   | 6           |
| 5.2.2 Basic movement of multifunction controls.....                    | 7           |
| 5.2.3 Machine responses to control change-over.....                    | 7           |
| 5.2.4 Additional controls located at a multifunction control.....      | 7           |
| <b>6 Control actuating forces</b> .....                                | <b>7</b>    |
| <b>Annex A (normative) Earth-moving machinery — Base machine</b> ..... | <b>9</b>    |
| <b>Annex B (normative) Earth-moving machinery — Equipment</b> .....    | <b>15</b>   |
| <b>Annex C (normative) Earth-moving machinery — Attachment</b> .....   | <b>21</b>   |
| <b>Annex D (informative) Graders</b> .....                             | <b>25</b>   |
| <b>Annex E (informative) Dozers</b> .....                              | <b>30</b>   |
| <b>Bibliography</b> .....  | <b>34</b>   |