

# ISO 10968:2020-05 (E)

## Earth-moving machinery - Operator's controls

---

<b>Contents</b>		<b>Page</b>
<b>Foreword</b> .....		<b>iv</b>
<b>Introduction</b> .....		<b>v</b>
<b>1 Scope</b> .....		<b>1</b>
<b>2 Normative references</b> .....		<b>1</b>
<b>3 Terms and definitions</b> .....		<b>1</b>
<b>4 Requirements for controls</b> .....		<b>4</b>
4.1 General.....		4
4.2 Control locations.....		4
4.3 Distance between controls.....		4
4.4 Measures against movement or damage by external forces.....		5
4.5 Pedals.....		6
<b>5 Movement of controls</b> .....		<b>6</b>
5.1 General.....		6
5.2 Multifunction controls.....		6
5.2.1 General.....		6
5.2.2 Basic movement of multifunction controls.....		7
5.2.3 Machine responses to control change-over.....		7
5.2.4 Additional controls located at a multifunction control.....		7
<b>6 Control actuating forces</b> .....		<b>7</b>
<b>Annex A (normative) Earth-moving machinery — Base machine</b> .....		<b>9</b>
<b>Annex B (normative) Earth-moving machinery — Equipment</b> .....		<b>15</b>
<b>Annex C (normative) Earth-moving machinery — Attachment</b> .....		<b>21</b>
<b>Annex D (informative) Graders</b> .....		<b>25</b>
<b>Annex E (informative) Dozers</b> .....		<b>30</b>
<b>Bibliography</b> .....		<b>34</b>