DIN EN 528:2021-06 (E)

Rail dependent storage and retrieval equipment - Safety requirements for S/R machines

Contents

Page

European foreword 6

Introduction 8

1 Scope 9

2 Normative references 9

3 Terms and definitions 11

4 Safety requirements and/or protective/risk reduction measures 14
4.1 General 14
4.2 Control position 14
4.2.1 General 14
4.2.2 Access to and egress from the permanent on-board control position 14
4.2.3 Floor of the on-board control position 14
4.2.4 Design and dimensioning of permanent on-board control position 14
4.2.5 Emergency call device on permanent on-board control positions 15
4.2.6 Lighting on permanent on-board control position 15
4.3 Control equipment 16
4.3.1 General 16
4.3.2 Safeguard of the operator on a permanent on-board control position 16
4.3.3 Prevention of unauthorised operation (equipment switch) 16
4.3.4 Changing mode of operation (mode switch) 16
4.3.5 Key dependence 17
4.3.6 Control devices for powered movements 17
4.3.7 Control device identification 17
4.3.8 Stop function 17
4.3.9 Emergency stop function 18
4.3.10 Safety requirements related to EMC 18
4.4 Hoist unit 18
4.4.1 Hoist unit brake 18
4.4.2 Limitation of the lifting and lowering movement 19
4.4.3 Overload and slack condition protection 19
4.4.4 Safety gear and overspeed governor 20
4.4.5 Suspension elements 21
4.4.6 Hydraulic drives 24
4.4.7 Lead-screw drive 24
4.4.8 Rack and pinion drives 25
4.5 Travel unit of the S/R machine 25
4.5.1 Travel unit braking system 25
4.5.2 Speed reducing system 26
4.5.3 Limitation of travel 26
4.5.4 Anti-derailment devices 27
4.5.5 Stability 27
4.6 Load handling devices 28
4.6.1 Load stability 28
4.6.2 Determination of possible impacts on the rack 28
4.6.3 Rotating devices 28
4.6.4 Interlocking functions 28
4.6.5 Auxiliary handling equipment 28

4.6.6 Load position monitoring 29
4.6.7 Satellites 29
4.7 Electrical equipment 29
4.7.1 General 29
4.7.2 Electrical supply conditions 29
4.7.3 Environment 29
4.7.4 Supply disconnecting (isolating) device 29
4.7.5 Protection against electric shock 30
4.7.6 Suspension of safeguarding 30
4.7.7 Overriding of safety functions 30
4.8 Transfer device 30
4.8.1 General 30
4.8.2 Retention of position 31
4.8.3 Movement 31
4.8.4 Interlocking functions 31
4.8.5 Stability 31
4.9 Maintenance repair and fault clearance 31
4.9.1 General 31
4.9.2 Maintenance position 31
4.9.3 Emergency control position 32
4.9.4 Speed limitation 32
4.9.5 Communication 33
4.9.6 Protection from operating machines (S/R machines and its transfer equipment) 33
4.9.7 Access along the mast 33
4.10 Machine environment 35
4.10.1 General 35
4.10.2 Communication of force information 35
4.10.3 Safety clearances 35
4.10.4 Safeguarding of persons (Limiting access) 35
4.10.5 Load entry / exit points 36
4.10.6 Escape from dangerous areas 37
4.10.7 Protection against unintentional load movement 38
4.10.8 Protection against falling 39

5 Verification of safety requirements and/or measures 39
5.1 Examination 39
5.1.1 General 39
5.1.2 Movements to be done 39
5.1.3 Test of the safety gear 39
5.1.4 Verification of the mechanical limits of travel 40
5.1.5 Test of the lowering control valve 40
5.1.6 Written record 40
5.2 EMC 40
5.3 Noise 40
5.3.1 General 40
5.3.2 Noise measurement 40
5.3.3 Declaration 41
5.4 Load tests 42
5.4.1 Test load 42
5.4.2 Static load test 42
5.4.3 Dynamic load test 42
5.4.4 Load test record 42

6 Information for use 42
6.1 General 42
6.2 Erection on site 42
6.3 Commissioning 42
6.3.1 Method statement 42
6.3.2 Instructions 43
6.3.3 Training 43
6.3.4 Safety devices 43
6.3.5 Individual elements of the machine 43

6.3.6 Integrated commissioning 43
6.4 Normal operation 43
6.4.1 General 43
6.4.2 Operation and use 43
6.4.3 Maintenance, repair and fault-clearing 43
6.4.4 Spare parts 43
6.4.5 Certification of suspension elements 43
6.4.6 Noise declaration 43
6.4.7 Test report 44
6.4.8 Minimum markings 44
6.4.9 Conditions for the safe operation of equipment 44
6.5 Fault finding/troubleshooting 47
6.5.1 General 47
6.5.2 Description of safe access and egress to trouble points on the S/R machine 47
6.5.3 Description of safe access and egress to trouble points at the interface between S/R machine and racking 47
6.5.4 Description of safe access and egress to trouble points at the interface between the S/R machine and the conveying system 47
6.5.5 Training 47
6.6 Rescue of persons 47
6.7 Maintenance, inspection, testing and training 47
6.7.1 General 47
6.7.2 Maintenance 47
6.7.3 Periodic maintenance and testing 48
6.7.4 Training 49
6.8 Dismantling 49

Annex A (informative) Figures 50

Annex B (normative) Performance levels according to EN ISO 13849-1:2015 58

Annex C (normative) Preventing access to dangerous movements across the load entry/exit points 65

C.1 General 65
C.2 Preventing access besides the conveyor 65
C.2.1 Preventing access between conveyor and fixed guards 65
C.2.2 Preventing access between conveyor tracks 66
C.3 Preventing access under the conveyor 67
C.4 Preventing access over the conveyor 67
C.4.1 General 67
C.4.2 Preventing access by limited opening height and tunnels 67
C.4.3 Preventing access by minimum height of conveying level 69
C.4.4 Preventing access by design of gravity roller conveyor 71
C.4.5 Preventing access by mechanical guards 73
C.5 Stopping the dangerous movement of the S/R-machines 75
C.6 Additional organizational measures 76

Annex D (normative) Access to restricted areas 77

Annex E (normative) Verification of safety requirements and/or measures 80

Annex F (normative) List of significant and relevant hazards 87

Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EU aimed to be covered 92

Bibliography 99