

DIN EN 528:2021-06 (E)

Rail dependent storage and retrieval equipment - Safety requirements for S/R machines

Contents		Page
European foreword		6
Introduction		8
1	Scope	9
2	Normative references	9
3	Terms and definitions	11
4	Safety requirements and/or protective/risk reduction measures	14
4.1	General	14
4.2	Control position	14
4.2.1	General	14
4.2.2	Access to and egress from the permanent on-board control position	14
4.2.3	Floor of the on-board control position	14
4.2.4	Design and dimensioning of permanent on-board control position	14
4.2.5	Emergency call device on permanent on-board control positions	15
4.2.6	Lighting on permanent on-board control position	15
4.3	Control equipment	16
4.3.1	General	16
4.3.2	Safeguard of the operator on a permanent on-board control position	16
4.3.3	Prevention of unauthorised operation (equipment switch)	16
4.3.4	Changing mode of operation (mode switch)	16
4.3.5	Key dependence	17
4.3.6	Control devices for powered movements	17
4.3.7	Control device identification	17
4.3.8	Stop function	17
4.3.9	Emergency stop function	18
4.3.10	Safety requirements related to EMC	18
4.4	Hoist unit	18
4.4.1	Hoist unit brake	18
4.4.2	Limitation of the lifting and lowering movement	19
4.4.3	Overload and slack condition protection	19
4.4.4	Safety gear and overspeed governor	20
4.4.5	Suspension elements	21
4.4.6	Hydraulic drives	24
4.4.7	Lead-screw drive	24
4.4.8	Rack and pinion drives	25
4.5	Travel unit of the S/R machine	25
4.5.1	Travel unit braking system	25
4.5.2	Speed reducing system	26
4.5.3	Limitation of travel	26
4.5.4	Anti-derailment devices	27
4.5.5	Stability	27
4.6	Load handling devices	28
4.6.1	Load stability	28
4.6.2	Determination of possible impacts on the rack	28
4.6.3	Rotating devices	28
4.6.4	Interlocking functions	28
4.6.5	Auxiliary handling equipment	28

4.6.6	Load position monitoring	29
4.6.7	Satellites	29
4.7	Electrical equipment	29
4.7.1	General	29
4.7.2	Electrical supply conditions	29
4.7.3	Environment	29
4.7.4	Supply disconnecting (isolating) device	29
4.7.5	Protection against electric shock	30
4.7.6	Suspension of safeguarding	30
4.7.7	Overriding of safety functions	30
4.8	Transfer device	30
4.8.1	General	30
4.8.2	Retention of position	31
4.8.3	Movement	31
4.8.4	Interlocking functions	31
4.8.5	Stability	31
4.9	Maintenance repair and fault clearance	31
4.9.1	General	31
4.9.2	Maintenance position	31
4.9.3	Emergency control position	32
4.9.4	Speed limitation	32
4.9.5	Communication	33
4.9.6	Protection from operating machines (S/R machines and its transfer equipment)	33
4.9.7	Access along the mast	33
4.10	Machine environment	35
4.10.1	General	35
4.10.2	Communication of force information	35
4.10.3	Safety clearances	35
4.10.4	Safeguarding of persons (Limiting access)	35
4.10.5	Load entry / exit points	36
4.10.6	Escape from dangerous areas	37
4.10.7	Protection against unintentional load movement	38
4.10.8	Protection against falling	39
5	Verification of safety requirements and/or measures	39
5.1	Examination	39
5.1.1	General	39
5.1.2	Movements to be done	39
5.1.3	Test of the safety gear	39
5.1.4	Verification of the mechanical limits of travel	40
5.1.5	Test of the lowering control valve	40
5.1.6	Written record	40
5.2	EMC	40
5.3	Noise	40
5.3.1	General	40
5.3.2	Noise measurement	40
5.3.3	Declaration	41
5.4	Load tests	42
5.4.1	Test load	42
5.4.2	Static load test	42
5.4.3	Dynamic load test	42
5.4.4	Load test record	42
6	Information for use	42
6.1	General	42
6.2	Erection on site	42
6.3	Commissioning	42
6.3.1	Method statement	42
6.3.2	Instructions	43
6.3.3	Training	43
6.3.4	Safety devices	43
6.3.5	Individual elements of the machine	43

6.3.6	Integrated commissioning	43
6.4	Normal operation	43
6.4.1	General	43
6.4.2	Operation and use	43
6.4.3	Maintenance, repair and fault-clearing	43
6.4.4	Spare parts	43
6.4.5	Certification of suspension elements	43
6.4.6	Noise declaration	43
6.4.7	Test report	44
6.4.8	Minimum markings	44
6.4.9	Conditions for the safe operation of equipment	44
6.5	Fault finding/troubleshooting	47
6.5.1	General	47
6.5.2	Description of safe access and egress to trouble points on the S/R machine	47
6.5.3	Description of safe access and egress to trouble points at the interface between S/R machine and racking	47
6.5.4	Description of safe access and egress to trouble points at the interface between the S/R machine and the conveying system	47
6.5.5	Training	47
6.6	Rescue of persons	47
6.7	Maintenance, inspection, testing and training	47
6.7.1	General	47
6.7.2	Maintenance	47
6.7.3	Periodic maintenance and testing	48
6.7.4	Training	49
6.8	Dismantling	49
Annex A (informative) Figures		50
Annex B (normative) Performance levels according to EN ISO 13849-1:2015		58
Annex C (normative) Preventing access to dangerous movements across the load entry/exit points		65
C.1	General	65
C.2	Preventing access besides the conveyor	65
C.2.1	Preventing access between conveyor and fixed guards	65
C.2.2	Preventing access between conveyor tracks	66
C.3	Preventing access under the conveyor	67
C.4	Preventing access over the conveyor	67
C.4.1	General	67
C.4.2	Preventing access by limited opening height and tunnels	67
C.4.3	Preventing access by minimum height of conveying level	69
C.4.4	Preventing access by design of gravity roller conveyor	71
C.4.5	Preventing access by mechanical guards	73
C.5	Stopping the dangerous movement of the S/R-machines	75
C.6	Additional organizational measures	76
Annex D (normative) Access to restricted areas		77
Annex E (normative) Verification of safety requirements and/or measures		80
Annex F (normative) List of significant and relevant hazards		87
Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EU aimed to be covered		92
Bibliography		99