ISO 12140-1:2020 (E)

Agricultural trailers and trailed equipment — Drawbar jacks — Part 1: Design safety, test methods and acceptance criteria

Contents

Foreword

1 Scope

2 Normative references

3 Terms and definitions

4 Design requirements

- 4.1 Base
- 4.2 Jack overtravel
- 4.3 Hydraulic jacks
- 4.4 Drop leg

5 Performance requirements

- 5.1 Crank effort
- 5.2 Corrosion protection
- 5.3 Water ingress
- 5.4 Basic rated life
- 5.5 Rated static compressive load capacity
- 5.6 Rated dynamic compressive load capacity
- 5.7 Rated static tensile load capacity
- 5.8 Rated dynamic tensile load capacity
- 5.9 Rated static side load capacity
- 5.10 Rated static side torque class

6 Jack stand system design verification tests

- 6.1 General procedures and installation of jack
- 6.2 Crank effort test
- 6.3 Jack overtravel test
- 6.4 Ground pressure calculation
- 6.5 Corrosion protection test
- 6.6 Rated static compressive load capacity test
- 6.7 Rated dynamic compressive load capacity test
- 6.8 Rated static tensile load capacity test
- 6.9 Rated dynamic tensile load capacity test
- 6.10 Rated static side load capacity test
- 6.11 Maintenance of the load
- 6.12 Acceptance criteria
- 6.12.1 General
- 6.12.2 Functional failure
- 6.12.3 Catastrophic failure

7 Information for use

- 7.1 Instructions
- 7.2 Markings
- 7.2.1 Load capacities
- 7.2.2 Torque class
- 7.2.3 Identification
- 7.2.4 Other markings

Page count: 13