

# DIN EN 474-11:2023-02 (E)

## Earth-moving machinery - Safety - Part 11: Requirements for earth- and landfill compactors

---

<b>Contents</b>		<b>Page</b>
European foreword .....		3
Introduction .....		5
<b>1</b>	<b>Scope</b> .....	<b>6</b>
<b>2</b>	<b>Normative references</b> .....	<b>6</b>
<b>3</b>	<b>Terms and definitions</b> .....	<b>7</b>
<b>4</b>	<b>Safety requirements and/or protective/risk reduction measures</b> .....	<b>7</b>
4.1	General .....	7
4.2	Operator's station .....	8
4.3	Seat .....	8
4.4	Steering system .....	9
4.5	Braking system .....	9
4.6	Stability .....	9
4.7	Lifting operation .....	9
4.8	Protective measures and devices .....	9
<b>5</b>	<b>Verification of the safety requirements and/or protective/risk reduction measures</b> .....	<b>9</b>
<b>6</b>	<b>Information for use</b> .....	<b>10</b>
6.1	General .....	10
6.2	Machine safety labels .....	10
6.3	Operator's manual .....	11
<b>Annex A (informative) List of significant hazards</b> .....		<b>12</b>
<b>Annex B (normative) Braking requirements for earth- and landfill compactors</b> .....		<b>17</b>
<b>B.1</b>	<b>Terms and definitions</b> .....	<b>17</b>
<b>B.2</b>	<b>General requirements</b> .....	<b>17</b>
<b>B.3</b>	<b>Test conditions</b> .....	<b>17</b>
<b>B.4</b>	<b>Performance test</b> .....	<b>19</b>
<b>Annex C (informative) Illustrations</b> .....		<b>21</b>
<b>Annex ZA (informative) Relationship between this European Standard and the essential requirements of Directive 2006/42/EC machinery, and amending Directive 95/16/EC (recast) [2006 L157] aimed to be covered</b> .....		<b>22</b>
<b>Bibliography</b> .....		<b>27</b>