

DIN EN 474-11:2023-02 (E)

Earth-moving machinery - Safety - Part 11: Requirements for earth- and landfill compactors

Contents	Page
European foreword	3
Introduction	5
1 Scope	6
2 Normative references	6
3 Terms and definitions	7
4 Safety requirements and/or protective/risk reduction measures	7
4.1 General	7
4.2 Operator's station	8
4.3 Seat	8
4.4 Steering system	9
4.5 Braking system	9
4.6 Stability	9
4.7 Lifting operation	9
4.8 Protective measures and devices	9
5 Verification of the safety requirements and/or protective/risk reduction measures	9
6 Information for use	10
6.1 General	10
6.2 Machine safety labels	10
6.3 Operator's manual	11
Annex A (informative) List of significant hazards	12
Annex B (normative) Braking requirements for earth- and landfill compactors	17
B.1 Terms and definitions	17
B.2 General requirements	17
B.3 Test conditions	17
B.4 Performance test	19
Annex C (informative) Illustrations	21
Annex ZA (informative) Relationship between this European Standard and the essential requirements of Directive 2006/42/EC machinery, and amending Directive 95/16/EC (recast) [2006 L157] aimed to be covered	22
Bibliography	27