

# ISO 29463-5:2022-03 (E)

## High-efficiency filters and filter media for removing particles in air - Part 5: Test method for filter elements

---

<b>Contents</b>		<b>Page</b>
Foreword .....		v
Introduction .....		vi
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms, definitions, symbols and abbreviated terms .....</b>	<b>1</b>
<b>3.1</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>3.2</b>	<b>Symbols and abbreviated terms .....</b>	<b>2</b>
<b>4</b>	<b>Efficiency test methods .....</b>	<b>3</b>
<b>4.1</b>	<b>Reference efficiency test method .....</b>	<b>3</b>
<b>4.2</b>	<b>Alternate efficiency test method for groups H and U filters .....</b>	<b>3</b>
<b>4.3</b>	<b>Statistical efficiency test method for low efficiency filters -- Group E filters .....</b>	<b>3</b>
<b>5</b>	<b>Test filter .....</b>	<b>4</b>
<b>6</b>	<b>Test apparatus .....</b>	<b>4</b>
<b>6.1</b>	<b>General .....</b>	<b>4</b>
<b>6.2</b>	<b>Test duct .....</b>	<b>5</b>
<b>6.2.1</b>	<b>Test air conditioning .....</b>	<b>5</b>
<b>6.2.2</b>	<b>Adjustment of the volume flow rate .....</b>	<b>5</b>
<b>6.2.3</b>	<b>Measurement of the volume flow rate .....</b>	<b>5</b>
<b>6.2.4</b>	<b>Aerosol mixing section .....</b>	<b>5</b>
<b>6.2.5</b>	<b>Test filter mounting assembly .....</b>	<b>6</b>
<b>6.2.6</b>	<b>Measuring points for the pressure drop .....</b>	<b>6</b>
<b>6.2.7</b>	<b>Sampling .....</b>	<b>6</b>
<b>6.3</b>	<b>Aerosol generation and measuring instruments .....</b>	<b>6</b>
<b>6.3.1</b>	<b>General .....</b>	<b>6</b>
<b>6.3.2</b>	<b>Apparatus for testing with a mono-disperse test aerosol .....</b>	<b>7</b>
<b>6.3.3</b>	<b>Apparatus for testing with a poly-disperse test aerosol .....</b>	<b>7</b>
<b>7</b>	<b>Conditions of the test air .....</b>	<b>11</b>
<b>8</b>	<b>Test procedure .....</b>	<b>12</b>
<b>8.1</b>	<b>Preparatory checks .....</b>	<b>12</b>
<b>8.2</b>	<b>Starting up the aerosol generator .....</b>	<b>12</b>
<b>8.3</b>	<b>Preparation of the test filter .....</b>	<b>12</b>
<b>8.3.1</b>	<b>Installation of the test filter .....</b>	<b>12</b>
<b>8.3.2</b>	<b>Flushing the test filter .....</b>	<b>12</b>
<b>8.4</b>	<b>Testing .....</b>	<b>12</b>
<b>8.4.1</b>	<b>Measuring the pressure drop .....</b>	<b>12</b>
<b>8.4.2</b>	<b>Testing with a mono-disperse test aerosol .....</b>	<b>13</b>
<b>8.4.3</b>	<b>Testing with a poly-disperse test aerosol .....</b>	<b>13</b>
<b>8.4.4</b>	<b>Testing filters with charged media .....</b>	<b>13</b>
<b>9</b>	<b>Evaluation .....</b>	<b>13</b>
<b>10</b>	<b>Test report .....</b>	<b>15</b>

<b>11</b>	<b>Maintenance and inspection of the test apparatus .....</b>	<b>16</b>
	<b>Annex A (normative) Alternate efficiency test method from scan testing .....</b>	<b>17</b>
	<b>Annex B (informative) Testing and classification method for filters with MPPS 0,1 µm (e.g. membrane medium filters) .....</b>	<b>18</b>
	<b>Annex C (normative) Method for testing and classification of filters using media with charged fibres .....</b>	<b>21</b>
	<b>Annex D (informative) Traditional efficiency test methods for HEPA and ULPA filters .....</b>	<b>27</b>
	<b>Bibliography .....</b>	<b>28</b>