

# ISO 29462:2022-07 (E)

## Field testing of general ventilation filtration devices and systems for in situ removal efficiency by particle size and resistance to airflow

---

Contents	Page
<b>Foreword .....</b>	<b>v</b>
<b>Introduction .....</b>	<b>vi</b>
<b>1 Scope .....</b>	<b>1</b>
<b>2 Normative references .....</b>	<b>1</b>
<b>3 Terms, definitions, and abbreviated terms .....</b>	<b>1</b>
<b>3.1 Terms and definitions .....</b>	<b>1</b>
<b>3.2 Abbreviated terms .....</b>	<b>3</b>
<b>4 Test equipment and setup .....</b>	<b>4</b>
<b>4.1 Particle counter .....</b>	<b>4</b>
<b>4.2 Diluter .....</b>	<b>4</b>
<b>4.3 Pump .....</b>	<b>4</b>
<b>4.4 Sampling system .....</b>	<b>4</b>
<b>4.4.1 General .....</b>	<b>4</b>
<b>4.4.2 Sampling probes .....</b>	<b>5</b>
<b>4.4.3 Sampling lines .....</b>	<b>5</b>
<b>4.4.4 Sampling locations .....</b>	<b>5</b>
<b>4.4.5 Valve (manual or automatic) .....</b>	<b>6</b>
<b>4.4.6 Isoaxial sampling nozzle .....</b>	<b>6</b>
<b>4.4.7 Flow meter .....</b>	<b>7</b>
<b>4.5 Air velocity measurement instrument .....</b>	<b>7</b>
<b>4.6 Relative humidity (RH) measurement instrument .....</b>	<b>7</b>
<b>4.7 Temperature measurement instrument .....</b>	<b>7</b>
<b>4.8 Resistance to airflow measurement instrument .....</b>	<b>7</b>
<b>4.9 Test equipment maintenance and calibration .....</b>	<b>7</b>
<b>5 Site evaluation .....</b>	<b>8</b>
<b>5.1 General .....</b>	<b>8</b>
<b>5.2 Filter installation pre-testing inspection .....</b>	<b>8</b>
<b>5.3 Approval for testing .....</b>	<b>8</b>
<b>6 Test procedure .....</b>	<b>8</b>
<b>6.1 Air velocity .....</b>	<b>8</b>
<b>6.2 Relative humidity (RH) .....</b>	<b>9</b>
<b>6.3 Temperature .....</b>	<b>9</b>
<b>6.4 Resistance to airflow .....</b>	<b>9</b>
<b>6.5 Removal efficiency .....</b>	<b>10</b>
<b>6.5.1 Removal efficiency tests .....</b>	<b>10</b>
<b>6.5.2 Sampling method .....</b>	<b>10</b>
<b>6.6 Sampling probes .....</b>	<b>14</b>
<b>6.6.1 Location of sampling probes .....</b>	<b>14</b>
<b>6.6.2 Location of upstream sampling probes .....</b>	<b>14</b>
<b>6.6.3 Location of downstream sampling probes -- Filter efficiency test .....</b>	<b>14</b>
<b>6.6.4 Location of downstream sampling probes -- System efficiency test .....</b>	<b>14</b>
<b>7 Expression of results .....</b>	<b>14</b>
<b>7.1 General information .....</b>	<b>14</b>

<b>7.2</b>	<b>Data collection .....</b>	<b>16</b>
<b>8</b>	<b>Errors and data analyses .....</b>	<b>17</b>
8.1	General .....	17
8.2	Relative humidity (RH) .....	17
8.3	Air temperature .....	17
8.4	Aerosol composition .....	17
8.5	Uniformity of aerosol concentration .....	17
8.6	Coincidence errors -- Particle counter .....	18
<b>8.7</b>	<b>Particle losses .....</b>	<b>18</b>
<b>9</b>	<b>Calculation of results .....</b>	<b>18</b>
9.1	Calculation of removal efficiency .....	18
9.1.1	General .....	18
9.1.2	Dataset sample average .....	18
9.1.3	Minimum upstream concentration .....	19
9.1.4	Particle size range efficiency .....	20
9.1.5	Average efficiency by particle size .....	20
9.2	Calculation of uncertainty .....	20
9.2.1	General .....	20
9.2.2	95 % confidence limit .....	20
9.3	Coefficient of variation (Cv) .....	21
<b>10</b>	<b>Optional enhanced test system .....</b>	<b>22</b>
10.1	Application of enhanced test system .....	22
10.2	Principle of the enhanced test system .....	22
10.3	Determination of the corrected particle size .....	23
10.4	Presentation of results .....	24
<b>Annex A (informative) Filter installation pre-testing inspection form .....</b>		<b>25</b>
<b>Annex B (informative) Approval for testing form .....</b>		<b>27</b>
<b>Annex C (informative) Example of how to complete testing .....</b>		<b>28</b>
<b>Bibliography .....</b>		<b>42</b>