

# DIN EN ISO 16119-5:2024-07 (E)

## Agricultural and forestry machinery - Environmental requirements for sprayers - Part 5: Aerial spray systems (ISO 16119-5:2023)

---

<b>Contents</b>	<b>Page</b>
<b>European foreword</b> .....	<b>3</b>
<b>Foreword</b> .....	<b>4</b>
<b>Introduction</b> .....	<b>5</b>
<b>1 Scope</b> .....	<b>6</b>
<b>2 Normative references</b> .....	<b>6</b>
<b>3 Terms and definitions</b> .....	<b>7</b>
<b>4 List of significant hazards</b> .....	<b>7</b>
<b>5 Requirements</b> .....	<b>8</b>
5.1 General.....	8
5.2 Sprayer tanks.....	8
5.2.1 Materials.....	8
5.2.2 Tank openings.....	8
5.2.3 Emptying.....	9
5.2.4 Tank contents indicator(s).....	9
5.2.5 Agitation.....	9
5.2.6 Filling pre-mix tank.....	9
5.3 Hoses and lines.....	10
5.4 Spray boom.....	10
5.4.1 Design and location.....	10
5.4.2 Adjustment.....	10
5.5 Safety measures.....	10
5.6 Filters.....	11
5.7 Nozzles/atomizers.....	11
5.8 Measuring systems.....	11
5.8.1 General.....	11
5.8.2 Provisions for connecting test equipment.....	12
5.9 Volume/area adjustment system.....	12
5.10 Distribution and control of spray drift.....	12
5.10.1 Distribution.....	12
5.10.2 Control of spray drift.....	13
5.10.3 Swathe marking/mapping.....	13
5.11 Cleaning.....	13
5.11.1 Cleaning devices at the sprayer.....	13
5.11.2 Water tanks.....	13
<b>6 Instruction handbook/Operator's manual</b> .....	<b>13</b>
<b>7 Markings</b> .....	<b>14</b>
<b>Annex A (informative) Guidelines, aerial deposition models and nozzle drop size category websites</b> .....	<b>15</b>
<b>Bibliography</b> .....	<b>16</b>