

# ISO 21815-3:2023-08 (E)

## Earth-moving machinery - Collision warning and avoidance - Part 3: Risk area and risk level for forward/reverse motion

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
1	Scope .....	1
2	Normative references .....	1
3	Terms and definitions .....	1
4	Performance requirements .....	7
4.1	General requirements .....	7
4.2	Calculating CxS distance .....	7
4.2.1	Forward/reverse motion .....	7
4.2.2	Collision risk area reduction .....	7
4.3	Determination of collision risk level .....	8
4.4	Collision warning and collision avoidance action .....	8
4.5	CxS action and expected machine speed behaviour .....	8
4.5.1	General .....	8
4.5.2	Requirement of D0 .....	8
4.5.3	CxS configuration .....	8
4.6	Collision warning system .....	9
4.6.1	System functionality .....	9
4.6.2	Discontinuation of warning signal and reactivation .....	9
4.6.3	Human interface requirements .....	9
4.7	Collision avoidance system .....	10
4.7.1	System functionality .....	10
4.7.2	Discontinuation of collision avoidance action and reactivation .....	10
4.7.3	Intervention indicator .....	11
5	Time and distance calculation guidance .....	11
5.1	General .....	11
5.2	CxS detection, determination and communication .....	11
5.3	Action time (TCD) and action distance (DCD) .....	11
5.4	CWS action time (TCD) .....	12
6	Information for use .....	12
6.1	General .....	12
6.2	Operator's manual .....	12
Annex A (normative) Determining of collision risk levels -- forward/reverse motion .....		13
Annex B (normative) Limitations of use of CxS .....		16
Annex C (informative) Example calculation CxS distance for surface vehicles .....		22
Annex D (informative) Example calculations of CxS distance for underground mining machine .....		24
Annex E (informative) Estimating the path .....		34
Annex F (informative) An approach for determining CxS configuration .....		38

<b>Annex G (informative) Types of interventional collision avoidance actions .....</b>	<b>44</b>
<b>Bibliography .....</b>	<b>48</b>