

ISO 10300-2:2023-08 (E)

Calculation of load capacity of bevel gears - Part 2: Calculation of surface durability (macropitting)

Contents		Page
Foreword		iv
Introduction		vi
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	Symbols, general subscripts and abbreviated terms	2
5	Macropitting damage -- General aspects	6
5.1	Acceptable versus unacceptable macropitting	6
5.2	Assessment requirements	6
5.3	General rating procedure	7
6	Gearflankratingformulae--MethodB1	7
6.1	Contact stress formula	7
6.2	Permissible contact stress	8
6.3	Calculated safety factor for contact stress	8
6.4	Contact stress factors	9
6.4.1	Mid-zone factor, ZM-B	9
6.4.2	Load sharing factor, ZLS	10
6.5	Permissible contact stress factors	11
6.5.1	Bevel gear factor, ZKP	11
6.5.2	Size factor, ZX	12
6.5.3	Hypoid factor, ZHyp	12
7	Gearflankratingformulae--MethodB2	15
7.1	Contact stress formula	15
7.2	Permissible contact stress	16
7.3	Calculated safety factor for contact stress	16
7.4	Contact stress factors	16
7.4.1	General	16
7.4.2	Macropitting resistance geometry factor, ZI	17
7.4.3	Facewidth factor, ZFW	20
7.4.4	Contact stress adjustment factor, ZA	20
8	Factors for contact stress and permissible contact stress common for method B1 and method B2	21
8.1	Elasticity factor, ZE	21
8.2	Lubricant film influence factors, ZL, Zv, ZR	21
8.2.1	General	21
8.2.2	Restrictions	21
8.2.3	Method B	21
8.2.4	Method C (product of ZL, Zv and ZR)	23
8.3	Work hardening factor, ZW	23
8.3.1	General	23
8.3.2	Work hardening factor, ZW: Method A	23
8.3.3	Work hardening factor, ZW: Method B	24

8.4	Life factor, ZNT	26
8.4.1	General	26
8.4.2	Method A	27
8.4.3	Method B	28
Annex A (informative) Local calculation method for surface durability (macropitting)- Method B1- localised		29
Bibliography		35