ISO 23725:2024-08 (E)

Autonomous system and fleet management system inter operability

Contents

Page

Foreword vi

Introduction vii

1 Scope 1

2 Normative references 1

3 Terms, definitions and abbreviations 1
3.1 Terms and definitions 2
3.2 Abbreviations 2

4 Computer communication 3
4.1 Session and transport layer 3
4.1.1 WebSocket client and service behaviour 4
4.2 Presentation layer 4
4.2.1 Container, serialization, and encoding 4
4.2.2 JSON container 4
4.2.3 NULL attribute 4
4.2.4 Units 4
4.2.5 On machine component arrays 5

5 Messaging 6
5.1 Overview 6
5.2 Event based messaging 6
5.3 Message header 7
5.3.1 General 7
5.3.2 Header example 7
5.4 Messages during connection outage 8
5.5 Out of standard message 8
5.5.1 General 8
5.5.2 Out of standard examples 8
5.6 Common attribute enumeration 9
5.6.1 General 9
5.6.2 Actor 9
5.6.3 Action request 9
5.6.4 Action response 10
5.6.5 Action status 10
5.6.6 Autonomy mode 10

6 System messaging 10
6.1 General 10
6.2 Fleet definition message 10
6.2.1 General 10
6.2.2 Fleet ID 12
6.2.3 Equipment type 12
6.2.4 Autonomous 13
6.2.5 Equipment length and width 13
6.2.6 Fleet definition example 13
6.3 Machine all-stop 15
6.3.1 Optional feature 15
6.3.2 Scope of effect 15

6.3.3 Machine all-stop status message 15
6.3.4 Machine all-stop request message 16
6.3.5 Machine all-stop response message 17
6.3.6 Machine all-stop examples 18

7 Generic machine telemetry 20
7.1 Message content 20
7.2 Data streams 20
7.3 Machine position 20
7.3.1 Machine coordinate system and frame of reference 20
7.4 Machine position message 21
7.4.1 Machine position examples 23
7.5 Basic machine health message 25
7.5.1 Basic machine health message example 27

8 Generic machine messaging 27
8.1 Message content 27
8.2 Machine autonomy mode message 27
8.3 Machine dispatch availability 28
8.3.1 General 28
8.3.2 Purpose 29
8.3.3 Machine Dispatch Availability message 29
8.3.4 Trigger the FMS to re-send an assignment 29
8.3.5 Impending custodian change 30
8.3.6 Machine dispatch availability example 30
8.4 Machine diagnostic message 32
8.4.1 General 32
8.4.2 Purpose 32
8.4.3 Component identification number 32
8.4.4 Fault Code number 33
8.4.5 AHS documentation 33
8.4.6 Connection time 33
8.4.7 When the last fault clears 33
8.4.8 Machine diagnostic message examples 34

9 Routing 35
9.1 Map connectivity 36
9.1.1 Purpose 36
9.1.2 Map Connectivity message 36
9.1.3 Clarification of unidirectionality of connections 37
9.1.4 Understanding the specification by example 37

10 Map service 44
10.1 Map object concepts 44
10.2 Map object identification number rules and restrictions 44
10.2.1 Restrictions on object identification numbers 44
10.2.2 Identification numbers rules for ways and nodes 45
10.3 Map format 45
10.3.1 Map document encoding 45
10.3.2 Splitting a large map into chunks 46
10.3.3 Point - node element 46
10.3.4 Line - way element 47
10.3.5 Road 48
10.3.6 Lane 48
10.3.7 Area 49
10.4 Adding context to objects 51
10.4.1 Tag Element Attribute Encoding 51
10.4.2 Standard tags 52
10.4.3 Tag with Attribute k = 'name' 52
10.4.4 Tag with Attribute k = 'default task' 53
10.4.5 Tag with Attribute k = 'autonomy' 53

10.4.6 Tag with Attribute k = 'autonomy:area' 54
10.4.7 Tag with Attribute k = 'oneway' 54
10.5 Map building 55
10.5.1 Connecting map objects 55
10.5.2 Building a purely structured road model 55
10.5.3 Purely structured rules 55
10.6 Map service messaging 56
10.6.1 Map service identification 56
10.6.2 Map Service Identification V1 56
10.6.3 Map summary 56
10.6.4 Map command - get summary 58
10.6.5 Map command - get all 59
10.6.6 Map document message 59

11 Interface diagnostic 60
11.1 Interface diagnostic information 60
11.1.1 Diagnostic measurement information 60
11.1.2 Diagnostic message information 61

12 Haul truck production 63
12.1 Message content 63
12.2 Production cycle message 63
12.3 Production cycle definition 63
12.3.1 Definition of a haul truck cycle 64
12.3.2 Proposed state decision tree 64
12.4 Haul truck production state message 65
12.4.1 Haul truck production state V2 66
12.5 Haul truck production state sensor V1 66
12.5.1 Haul truck production state sensor V1 67
12.6 Haul truck payload message 68
12.7 Operational context 69
12.8 Haul truck dump message 69

13 Haul truck assignment 70
13.1 Message content 70
13.2 Haul truck task assignment types 71
13.3 Haul truck assignment message 71
13.3.1 Precondition and behaviour 71
13.3.2 Current assignment 71
13.3.3 Future assignment 71
13.3.4 Responsibility of safe execution 71
13.3.5 Haul truck assignment request message 71
13.3.6 Haul truck assignment response message 73
13.3.7 Haul truck assignment rejection 75
13.3.8 Haul truck assignment reset message 76
13.3.9 Haul truck assignment message 77

Annex A (informative) Example of message exchange 79

Annex B (informative) External IT infrastructure 86

Bibliography 87